


# SONY

make.believe

---

## Test Instructions

- mechanical -



**Xperia™ Z2**  
**L50t, L50u**

## CONTENTS

<b>1</b>	<b>Pre-Test Preparation .....</b>	<b>4</b>
1.1	Process flow – Water Resistance Test (WRT) for incoming units ....	4
1.2	Hardware.....	5
1.2.1	Water indicator inspection.....	5
1.3	Test Enablers.....	6
1.4	Software.....	7
1.4.1	Software update.....	7
<b>2</b>	<b>Tests .....</b>	<b>8</b>
2.1	Service Test Mode.....	8
2.2	Service Tests.....	9
2.2.1	Keyboard & Switch.....	9
2.2.1	Touch Screen.....	9
2.2.2	Display.....	9
2.2.3	LED/Illumination .....	10
2.2.4	Speaker.....	10
2.2.5	Stereo speaker .....	10
2.2.6	Earphone .....	11
2.2.7	Microphone .....	11
2.2.8	Secondary Microphone .....	12
2.2.9	Vibrator.....	13
2.2.10	Camera .....	13
2.2.11	Secondary Camera .....	13
2.2.12	Flash LED .....	14
2.2.13	Antenna Switching .....	14
2.2.14	Bluetooth.....	14
2.2.15	WLAN.....	15
2.2.16	NFC .....	15
2.2.17	GPS.....	16
2.2.18	Compass .....	16
2.2.19	Accelerometer.....	16
2.2.20	Gyroscope.....	17
2.2.21	Ambient Light Sensor .....	18
2.2.22	Proximity switch.....	18
2.2.23	Pressure Sensor .....	18
2.2.24	Real time clock .....	19
2.2.25	Total call time.....	19
2.2.26	Storage .....	19
2.2.27	Security .....	20
2.2.28	FM Radio .....	20
2.2.29	Battery Health test.....	20
2.2.30	Verify certificates.....	21
2.2.31	TV-Out Test .....	21
<b>2.3</b>	<b>Manual Tests .....</b>	<b>23</b>
2.3.1	SIM test.....	23
2.3.2	On/Off key test .....	23
2.3.3	Home key test .....	23

2.3.4	Multitask key test.....	24
2.3.5	Data Communication test .....	24
2.3.6	Audio Jack test .....	25
2.3.7	Charging (Charger or Computer) .....	26
2.4	Battery Test .....	28
2.5	Network Test.....	29
2.5.1	Procedure (GSM & UMTS & TDSCDMA) .....	29
2.5.2	On-the-air call to mobile-L50t Specific .....	30
2.5.3	On-the-air call to mobile-L50u Specific .....	31
3	Calibrations.....	32
4	Revision History .....	33


**For general information about test procedures, refer to  
1220-1333: Generic Repair Manual – mechanical**

## 1 Pre-Test Preparation

### 1.1 Process flow – Water Resistance Test (WRT) for incoming units

Follow the process according to the 1269-3536 Water Resistant Test for PC - mechanical in the including document Test Instruction WRT


Remove the Panel Bottom following Working Instruction-.




Install the "WRT Inlay plate" into the generic "WRT Generic Side Inlay"

Connect it according to 1269-3536 Water Resistant Test for PC - mechanical in the including document Test Instruction WRT.

**Notice! Secondary microphone hole on the top of the phone must be sealed before test.**



Attach the Panel Bottom following Working Instruction-.



## Pre-Test Preparations

### 1.2 Hardware

#### 1.2.1 Water indicator inspection

Before starting any tests the Liquid Indicator has to be checked.

The indicator is located as shown in this picture after the Cap USB is opened.



Another indicator is located as shown in this picture after the Cap SIM is opened.



Other indicator is located as shown in this picture after the Cap SD is opened.




## Pre-Test Preparations

### 1.3 Test Enablers

These are items on the phone that are used during the test of the unit.


#### Front:

1. Back Key
2. Home Key
3. Multi Key
4. Menu key
5. Ambient Sensor and Proximity Switch
6. Secondary Camera
7. Top Speaker and Notification LED
8. Microphone and Loudspeaker



#### Back:

9. On/Off Key
10. Volume up/down Key
11. Camera key
12. Camera
13. Secondary Microphone
14. NFC
15. LED Flash
16. Audio Jack
17. Magnetic connector (to dock)



## Pre-Test Preparations

### 1.4 Software

#### 1.4.1 Software update

##### 1.4.1.1 Software version verification

Check the software version of the phone for fault verification. The latest improvements are found on the support pages under the support news

<http://www.sonyericsson.com/cws/marketingurlportal?pageid=key.SupportZone.Overview>

- Start up the phone
  - Note: Make sure the phone is in call setup.
- Press the following keypad combination: **\*##7378423#\*#\***
- Select 'Service info'
- Select 'Software info'
- Check the software file revisions and, if needed, update as described below:

**For more information, refer to 1220-1333: Generic Repair Manual - mechanical**

##### 1.4.1.2 Software version update

**Mandatory first repair action!**

**Use the USB cable to connect with the Micro USB connector of the phone for this purpose!**

Ensure the phone is powered off and proceed as follows:

- Open the Emma application and log in.
- Press and hold the volume down key on the phone, connect the phone to the USB cable and then release the volume down key.
- Select the appropriate service and follow the on-screen instructions.

**Note: For phones with eMMC flash memory (built in "SD card" memory), the only service which erase this eMMC memory is Service's "Refurbish" and "Customize". See also Emma User Guide info. [http://emma.extranet.sonyericsson.com/documents/emma\\_user\\_guide.pdf](http://emma.extranet.sonyericsson.com/documents/emma_user_guide.pdf) (see "Service Types" and "Aspects of large files")**

**In Swap flow, when change a phone from Customer A to Customer B, always use the service Customization script.**

## 2 Tests

### 2.1 Service Test Mode

**Note: Make sure the phone is in call setup when pressing these touching keypads to get into the Service menu!**

**Stamina mode needs to be turned off before entering Service Test Mode**

**Settings -> Power management -> STAMINA**

Start up the phone and enter the service menus:

- Press the following keypad combination: **\*\*\*#7378423#\*\***

- Select 'Service tests'
- Select one of the tests and follow the test instructions as described below
- To stop the test and return to the 'Service tests' menu, press the Back key

**Service info: information about Model, Software, Simlock, Configuration (IMEI, bands, codec's) ,Firmware, WLAN Mac address etc.**



**Service settings: Do not use**

**Service test: Follow instruction below**

**Calibration: Do not use**

**Customization Settings: Do not use.**

**For more information, refer to 1220-1333: Generic Repair Manual - mechanical**



**The following pictures will show a simplified basic phone for a general visualization of the service tests!**



## Tests

### 2.2 Service Tests


#### 2.2.1 Keyboard & Switch

**Text Note: The Home Key, On/Off key and Multitask Key are not part of the keyboard test, but are in the Manual tests.**

**To return to the Service Test Menu, wait for 8 seconds.**

Press all keys on the:

- Back key
- Menu key
- Volume up key
- Volume down key
- Auto Focus/Camera key




#### 2.2.1 Touch Screen

Move a finger across the touch screen, a line will be drawn as it touches.

Check all area of the touch screen as indicated by the two lines.

Press the Back key to return to the Service Test Menu.



#### 2.2.2 Display


**Minor variations in the display's brightness and color may occur between phones.**

**There may be tiny bright dots on the display, called defective pixels and which occur when individual dots have malfunctioned and cannot be adjusted.**

**Two defective pixels are considered to be acceptable.**

Touch the display using a finger. With every touch, the display will show Nine test patterns of White, Gray, Black, Red, Green, Blue, Rainbow Colors, Cross-Line, TV Pattern on the full screen. Make sure that there are no missing segments and that the colors and contrast are OK.

Press the Back key to return to the Service Test Menu.




## Tests: Service Tests

### 2.2.3 LED/Illumination

Check that the:

- Display Backlight illumination goes from low to high strength back to low again.
- Notification LED changes, showing four colors in the following sequence: red, red, green, green, blue, blue and off.

Press the Back key to return to the Service Test Menu.




### 2.2.4 Speaker

**Do not hold the phone close to an ear during this test!**

Make sure that the sound from the Loudspeaker port is emitted loud and clear and that the test includes maximum volume.

Press the volume up/volume down key to adjust the Loudspeaker volume.

Press the Back key to return to the Service Test Menu.




### 2.2.5 Stereo speaker

**Do not hold the phone close to an ear during this test!**

Make sure that the left channel sound from the Top speaker port is emitted loud and clear and that the test includes maximum volume.

Press the volume up/volume down key to adjust the speaker volume.




## Tests: Service Tests

Make sure that the right channel sound from the Loudspeaker port is emitted loud and clear and that the test includes maximum volume.

Press the volume up/volume down key to adjust the Loudspeaker volume.

Press the Back key to return to the Service Test Menu.




### 2.2.6 Earphone

Make sure that the sound from the Top speaker port is emitted loud and clear and the test includes maximum volume.

Press the volume up/volume down key to adjust the Top speaker volume.

Press the Back key to return to the Service Test Menu.




### 2.2.7 Microphone

**The previous 'Speaker' test must have been successfully carried out before doing this test!**

The phone will start to record and after approximately ten seconds the sound is played back through the loudspeaker.


Step 1: Speak into the microphone during the 'Microphone Recording' phase;



## Tests: Service Tests

Step 2: Check the quality by listening to the recording from the loudspeaker during the 'Playing recorded sound' phase at maximum volume.

Press the Back key to return to the Service Test Menu.




### 2.2.8 Secondary Microphone

**The previous 'Speaker' test must have been successfully carried out before doing this test!**


The phone will start to record and after approximately ten seconds the sound is played back through the loudspeaker.

Step 1: Speak into the secondary microphone during the 'Microphone Recording' phase;



Step 2: Check the quality by listening to the recording from the loudspeaker during the 'Playing recorded sound' phase at maximum volume.

Press the Back key to return to the Service Test Menu.




## Tests: Service Tests

### 2.2.9 Vibrator

Press the Menu key or side keys to start the vibrator test.  
It is possible to modify the duration of this test.

Press the Back key to return to the Service Test Menu.



### 2.2.10 Camera


**Minor variations in image appearance may occur between phones, but is not uncommon and should not be regarded as an indication of a defective camera module!**

Aim the camera (located at the back of the phone) at an object and check the quality of the image shown in the display.

Touch the screen to take picture and preview the photo's auto focus quality.

**Photos are taken but not saved during this test!**

Press the Back key to return to the Service Test Menu.



### 2.2.11 Secondary Camera

**Minor variations in image appearance may occur between phones, but is not uncommon and should not be regarded as an indication of a defective camera module!**

Aim the camera (located in front of the phone) at an object and check the quality of the image shown in the display.

Press the Back key to return to the Service Test Menu.




## Tests: Service Tests

### 2.2.12 Flash LED

Check the Flash LED at the back side of phone whether it's turned on.


Press Back key to return to Service Test Menu.



### 2.2.13 Antenna Switching

N/A.

**Do not use this test!**



### 2.2.14 Bluetooth

**During this test, the distance between the phone and the target Bluetooth device must be 1.5 to 5 meters! Make sure the target Bluetooth device is enabled and visible always!**


The Bluetooth test will be done in following sequences:

Step 1: Enable Bluetooth; wait 4-5 seconds, shows OK;

**There is a permission request, select 'Yes'.**

Step 2: Searching;


Step 3: Show the Device Found list;



## Tests: Service Tests

- Step 4: Select the Target Bluetooth Device, and type the PIN code to pair;
- Step 5: Type the Pairing PIN code on the Target Bluetooth Device also, when successful, it shows 'Test Complete'.


Press the Back key to return to the Service Test Menu.



### 2.2.15 WLAN

**Make sure there's a WLAN network before performing this test.**

- The WLAN test will be done in following sequences:
- Step 1: Enable WLAN; wait 4-5 seconds, shows OK;
- Step 2: Searching;
- Step 3: Access points found list;
- Step 4: Select the Target WLAN network, and type the password to get connected;
- Step 5: Enter a web address (e.g. Google.com);
- Step 6: When connection succeeded, it shows 'Test Complete'.
- Press the Back key to return to the Service Test Menu.




### 2.2.16 NFC

**A NFC SIM card 3FF should be inserted in the phone before the start of this test!**

- The NFC test will be done in following sequences:
- Step 1: Select 'NFC';
- Step 2: Select 'NFC Diag Test';
- Step 3: After 'Tag Reading...Enabled' can be seen on the display, bring a NFC Tag close to middle of Rear Cover Assy.

**Don't touch each other to avoid Window Back scratch.**

Press the Back key two times to return to Service Test Menu.




## Tests: Service Tests

### 2.2.17 GPS

Enter the GPS Location Test and wait for the GPS location data.

Press the Back key to return to the Service Test Menu.


**For GPS testing, refer to  
1220-1333: Generic Repair Manual – mechanical**



### 2.2.18 Compass

Do calibration with hand movements as shown in the phone, and then check the actual direction with measured value.  
(Yaw:0=North, 90=East, 180=South, 270=West)


Press the Back key to return to the Service Test Menu.



### 2.2.19 Accelerometer

The accelerometer test displays the actual position of the phone as a 3D coordinate X: Y: Z.

Press the Back key to return to the Service Test Menu.






## Tests: Service Tests

By tilting the phone in various directions, the X: Y: Z values will change in size and polarity depending on the angle and direction as shown in the adjacent picture.

Check by tilting the phone that the X: Y: Z values shown in the display are in accordance with the tilting shown in the picture.

Press the Back key to return to the Service Test Menu.




### 2.2.20 Gyroscope

The gyroscope test displays the actual position of the phone as a 3D coordinate X: Y: Z.

Check by moving the phone that the X: Y: Z values shown in the display are in accordance with the moving.


Press the Back key to return to the Service Test Menu.



Check 'Gravity Values' 'Linear Acceleration Values' 'Rotation Vector Values' and 'Gyroscope Values' by moving the phone:

'Gravity Values' can be refer to Accelerometer;  
'Linear Acceleration Values' and 'Rotation Vector Values' are in accordance with the action shown in the picture.  
'Gyroscope Values' are updated while moving the phone.

Press the Back key to return to the Service Test Menu.




## Tests: Service Tests

### 2.2.21 Ambient Light Sensor

The Ambient light test states a value. The value should increase when the window gets more light and decrease when the window gets less light.

Press the Back key to return to the Service Test Menu.




### 2.2.22 Proximity switch

**The previous Chapter 2.2.4 'Speaker' test should have been successfully carried out before doing this test! Make sure the phone is not in 'silent mode' before performing this test.**

When entering into the test, the screen shows 'Proximity switch OFF' and a tone is emitted.

When covering the proximity switch area, the screen will show 'Proximity switch ON' with a different type of tone.

Press the Back key to return to the Service Test Menu.




### 2.2.23 Pressure Sensor

The Pressure Sensor test will check the atmospheric pressure around the phone and states a value. When you put the phone on the floor, read the value. When you raise the phone up as high as you can, the value should decrease about 0.2Millibars.

If the value shouldn't be static.

Press Back key to return to Service Test Menu.




## Tests: Service Tests

### 2.2.24 Real time clock

During the actual test the text 'Real time clock' is displayed, and then followed by a message stating whether the test was OK or not.


Press the Back key to return to the Service Test Menu.



### 2.2.25 Total call time

The total call time is displayed in the format HH:MM:SS (hours: minutes: seconds).

Press the Back key to return to the Service Test Menu.



### 2.2.26 Storage

Memory Storage status:

- Internal Mass Storage is 'Inserted/Mounted' as shown on the screen.


**A memory card should be inserted in the phone before starting this test!**

- The External Storage (SD Card) status is shown on the screen.

**Attach USB Adaptor between phone and an USB disk before starting this test!**

- The USB Host Mass Storage status is shown on the screen.

Press the Back key to return to the Service Test Menu.




## Tests: Service Tests

### 2.2.27 Security

The DRM keys are shown in the display.  
There may be different content shown based on different market software versions.


Press the Back key to return to the Service Test Menu.



### 2.2.28 FM Radio

Verify that the phone can detect a radio station:  
Connect a headset and then set your local radio station in Hz.  
Verify that the reception and sound quality is normal.


Press the Back key to return to the Service Test Menu.



### 2.2.29 Battery Health test

N/A.

***This test is not available for this product!***




## Tests: Service Tests

### 2.2.30 Verify certificates

When entering the test, four information categories will be shown: Media, Shared, Platform and Application.

**Do not use this test!**


Press the Back key to return to the Service Test Menu.




### 2.2.31 TV-Out Test

**MHL adapter, HDMI Type A Cable, charger and TV should be connected with the phone before the start of this test!**

Step 1: Attach cable between phone and TV-Out as shown in picture;



Only symbolic view




MHL TV Out is turned on after connection.

## Tests: Service Tests

Step 2: Press 'Play Video'.

Receive a test tone and a red-green-blue test picture in the TV-Out Monitor and phone.

**Note: If the TV-Out Monitor doesn't automatically identify the picture, the Monitor may require to set the TV-Out port chosen as source manually in the Monitors menus.**




Only symbolic view

Step3: Press 'Chess board pattern' to do the same test as the 'Play video'.

Step4: Press 'Gray ramp pattern' to do the same test as the 'Play video'.

Press the Back key to return to the Service Test Menu.



## Tests: Manual Tests

### 2.3 Manual Tests

#### 2.3.1 SIM test

Verify that the phone can detect a SIM card:

Step 1: Insert a SIM card, and start the phone;

If the SIM card is detected by the phone, the start-up procedure will continue.

Step 2: The operator's name is displayed at the bottom of the locked screen.

If not detected, the message 'No SIM card-Emergency call only' will be displayed instead.

If operator is not detected, the message 'No service' will be displayed instead.

Press Back key to return to Standby Menu.



#### 2.3.2 On/Off key test

Press the on/off key for a long time to turn the phone on or off.

Press the on/off key for a short time to enter Sleep mode or to wake it up from Sleep mode.



Only symbolic view

#### 2.3.3 Home key test

Whatever the phone shows now during operation, press the Home key for the phone go directly back to the Standby screen.




Only symbolic view

## Tests: Manual Tests

### 2.3.4 Multitask key test


Whatever the phone shows now during operation, press the Multitask key to show the programs used recently.



Only symbolic view

### 2.3.5 Data Communication test

- Connect a USB cable from a computer to the started phone.
- Verify that Data Communication works by transferring a file from Computer to phone
- Erase the file



Only symbolic view




## Tests: Manual Tests

### 2.3.6 Audio Jack test

Connect a Sony Noise canceling headset  
(see [www.sonymobile.com](http://www.sonymobile.com) go to the product and then Accessories for applicable headset)

Repeat the test of "2.2.6 Earphone"

Make sure that the sound to and from Headset is emitted loud and clear and that the units Notification panel at the top show "5-pin audio accessory connected" briefly when you attach the headset.




Only symbolic view

Go to Setting app, Sound / Audio Accessories

Tick the Stereo mic STM10, the faint white noise in the Headset should disappear.

Remove the Sony Noise canceling headset and press task key and chose the Service test again.




Connect a Sony CTIA headset (with microphone).

(see [www.sonymobile.com](http://www.sonymobile.com) go to the product and then Accessories)

Repeat the test of "2.2.7 Microphone".

Make sure that the sound to and from Headset is emitted loud and clear.



Only symbolic view

## Tests: Manual Tests

### 2.3.7 Charging (Charger or Computer)

#### 2.3.7.1 Charging via Magnetic connector (Charger or Computer)

Verify that the phone can charge the battery by using a Magnetic connector:

Connect a DK36 Magnetic Charging Dock from a computer or charger to the phone.

Verify that the phone is being charged by the notification LED and Battery icon in the display.

Remove the DK36 Magnetic Charging Dock from the connector and verify that the notification LED and Battery icon no longer indicates charging.



#### 2.3.7.2 Charging via USB (Charger or Computer)

Verify that the phone can charge the battery by a USB port:


**Ensure that no computer application, such as PC Suite or Emma, is active!**

**Do not start the phone.**

Connect a USB cable from a computer or charger to the phone.

Verify that the phone is being charged by the notification LED and Battery icon in the display.


Remove the USB cable from the connector and verify that the notification LED and Battery icon no longer indicates charging.



Only symbolic view

The Notification LED colour status is depended on battery remaining capacity:

- Red: Battery level is between 1% and 10%;
- Orange: Battery level is between 11% and 89%;
- Green: Battery is between 90% and 100%;



Only symbolic view

## Tests: Manual Tests


If above fails, perform below Diagnostic battery / Charging Status check.

Perform a force shut down by pressing the OFF button as shown in picture, until the unit vibrates three times then release the button. Then the phone will shut down.

If no vibration is detected, the battery might be discharged.



### Diagnostic Battery / Charging Status



The picture in above flow chart is only symbolic view.

**If the phone doesn't seem to charge,**

- **Disconnect the USB cable from the phone and then plug it into the Micro USB port on the phone again.**
- **It may take a few minutes before the battery light lights up when you connect the phone to a power source. If the battery is drained, it may take up to 30 minutes for the phone to respond to the charging. During this time, the screen may stay completely dark, not showing a charging icon.**
- **Make sure you use the Sony™ USB cable and power adapter that come with your phone, and that the cable is properly connected to the phone and the power adapter.**
- **Charge the phone using another USB cable, or charge the phone from a computer USB port, to rule out whether there is something wrong with the cable or the power adapter.**

## Tests

### 2.4 Battery Test

If bad battery performance or capacity problem is claimed, the battery and charging function can be tested by using an application designed for this purpose.

By using this application the battery is tested in a fast and controlled environment.

This is especially convenient when phones with embedded batteries should be checked, to avoid unnecessary work to disassembly the phone to access the battery.

This test is designed to identify a faulty battery or a hardware issue in the phone or with the charger. The guide will describe different procedures depending on the battery level when the battery test is initiated.

The test is downloaded to the phone, using cable or Bluetooth, and executed.



The test is available in CSPN at Level: Mechanical,

Title: **Sony Mobile Battery test Application 1266-2711.**

Unzip this file, where you find the application, installation and user guide content.

After the test the Sony Mobile Battery test.apk shall be removed by tap “Uninstall” “OK” in the application.

Error messages are described in the user guide for the Sony Mobile Battery test.



## Tests

### 2.5 Network Test


***This test can only be performed if the phone has an activated SIM/USIM/UIM card (no Test SIM/USIM/UIM) and an available network signal!***

***There are different versions of the test depending on whether a LTE, UMTS or TDSCDMA network is available or not!***

***If a LTE, UMTS or TDSCDMA network is available, the network test has to be done separately for GSM, UMTS, TDSCDMA or LTE!***

#### 2.5.1 Procedure (GSM & UMTS & TDSCDMA)

- Step 1: Set up a call from a landline phone (PSTN).
- Step 2: Check that there is a ring signal.
- Step 3: Check that the display backlight illuminates.
- Step 4: Answer the call and check the sound quality in both phones.
- Step 5: Adjust the volume up and down with the side keys and verify that the sound level is altered.
- Step 6: End the call and check that the elapsed time is displayed and that the termination is done properly.



Only symbolic view

## Tests: Network Test

### 2.5.2 On-the-air call to mobile-L50t Specific

#### GSM

Go to the Setting app:

Settings ⇒ *More* ⇒ *Mobile Networks* ⇒ Network mode ⇒ 3G (*preferred*)/ 2G

Ensure that the Network Status icon show signal strength and show no symbol or E at the top of the display.

To verify the radio functions (GSM) of the phone, follow the '2.5.1 Procedure (GSM & UMTS & TDSCDMA)' above.

#### TDSCDMA

Go to the Setting app:

Settings ⇒ *More* ⇒ *Mobile Networks* ⇒ Network mode ⇒ 3G (*preferred*)/ 2G

Ensure that the Network Status icon show signal strength and show 3G at the top of the display.

To verify the radio functions (TDSCDMA) of the phone, follow the '2.5.1 Procedure (GSM & UMTS & TDSCDMA)' above.

#### TD LTE (if available)

Go to the Setting app:

Settings ⇒ *More* ⇒ *Mobile Networks* ⇒ Network mode ⇒ 4G (*preferred*)/ 3G/ 2G

Ensure that the Network Status icon show signal strength and show LTE at the top of the display.

To verify the radio functions (LTE) of the phone, download data package by for ex. accessing the web.

Network Type can be checked in ⇒ *settings* ⇒ *about phone* ⇒ *status* ⇒ *Mobile Network Type*

## Tests: Network Test

### 2.5.3 On-the-air call to mobile-L50u Specific

#### GSM

Go to the Setting app:

Settings ⇒ More ⇒ Mobile Networks ⇒ Network mode ⇒ GSM only

Ensure that the Network Status icon show signal strength and show no symbol or E at the top of the display.

To verify the radio functions (GSM) of the phone, follow the '2.5.1 Procedure (GSM & UMTS & TDSCDMA)' above.

#### UMTS

Go to the Setting app:

Settings ⇒ More ⇒ Mobile Networks ⇒ Network mode ⇒ WCDMA only

Ensure that the Network Status icon show signal strength and show 3G or H+ (HSPA) at the top of the display.

To verify the radio functions (UMTS) of the phone, follow the '2.5.1 Procedure (GSM & UMTS & TDSCDMA)' above.

#### TD LTE (if available)

Go to the Setting app:

Settings ⇒ More ⇒ Mobile Networks ⇒ Network mode ⇒ LTE (preferred)/WCDMA/GSM

Ensure that the Network Status icon show signal strength and show LTE at the top of the display.


To verify the radio functions (LTE) of the phone, download data package by for ex. accessing the web.

Network Type can be checked in ⇒ settings ⇒ about phone ⇒ status ⇒ Mobile Network Type

## 3 Calibrations

**Service Menu, Calibrations, do not use!**

**See the products Working Instruction for Calibration instruction.**





## 4 Revision History

Rev.	Date	Changes / Comments
1	2014-Apr-01	Initial release
2	2014-Apr-25	Added L50u