

Test Instructions

- mechanical -



Xperia™ Z3+
E6553

Xperia™ Z3+ Dual
E6533

CONTENTS

Pre-Test Preparation	4
1.1 Process flow – Water Resistance Test (WRT) for incoming units	4
1.2 Hardware.....	5
1.2.1 Water indicator inspection (E6553).....	5
1.2.2 Water indicator inspection (E6533).....	5
1.3 Test Enablers.....	6
1.4 Software.....	7
1.4.1 Software update.....	7
2 Tests	8
2.1 Service Test Mode.....	8
2.2 Service Tests.....	9
2.2.1 Keyboard & Switch.....	9
2.2.1 Touch Screen.....	9
2.2.2 Display.....	9
2.2.3 LED/Illumination	10
2.2.4 Speaker.....	10
2.2.5 Stereo speaker	10
2.2.6 Earphone	11
2.2.7 Microphone	11
2.2.8 Secondary Microphone	12
2.2.9 Vibrator.....	12
2.2.10 Camera	13
2.2.11 Secondary Camera	13
2.2.12 Flash LED.....	13
2.2.13 Antenna RX Diversity	14
2.2.14 Bluetooth.....	14
2.2.15 WLAN.....	15
2.2.16 NFC	15
2.2.17 GPS.....	15
2.2.18 Compass	16
2.2.19 Accelerometer.....	16
2.2.20 Gyroscope.....	17
2.2.21 Ambient Light Sensor	17
2.2.22 Proximity switch.....	18
2.2.23 Hall Element Test.....	18
2.2.24 Pressure Sensor	18
2.2.25 Real time clock	19
2.2.26 Total call time (E6553).....	19
2.2.27 Total call time (E6533).....	19
2.2.28 Storage	20
2.2.29 Security	20
2.2.30 FM Radio	20
2.2.31 Verify certificates.....	21
2.2.32 TV-Out Test	21
2.2.33 WLAN Antenna TX/RX.....	23
2.3 Manual Tests	24
2.3.1 SIM test (E6553).....	24

2.3.2 SIM test (E6533) 24

2.3.3 Data Communication test 24

2.3.4 Audio Jack test 25

2.3.5 Charging (Charger or Computer) 26

2.3.6 Battery Test 28

2.3.7 Network Test 29

3 Revision History 30

For general information about test procedures, refer to
1220-1333: Generic Repair Manual – mechanical

Pre-Test Preparation

1.1 Process flow – Water Resistance Test (WRT) for incoming units

Follow the process according to 1269-3536 Water Resistant Test for PC - mechanical in the including document Test Instruction WRT.

Insert the unit in “WRT Inlay plate” and connect it to WRT test equipment.

Connect phone according to 1269-3536 Water Resistant Test for PC - mechanical in the including document Test Instruction WRT.

Note! Close the cap and seal the secondary microphone hole on the top of the phone before test. The unit's back side should be up in the WRT fixture! Make sure you insert the black pin in the Audio jack carefully and tighten the screws to secure proper position and good sealing of ventilation hole. The black handle is for Liquid test.




Pre-Test Preparations

1.2 Hardware

1.2.1 Water indicator inspection (E6553)

Before starting any tests the Liquid Indicator has to be checked.


The indicator is located as shown in picture in the Nano SIM and Memory card slot after Cap SIM/SD is opened.



1.2.2 Water indicator inspection (E6533)

Before starting any tests the Liquid Indicator has to be checked.

The indicator is located as shown in picture in the Nano SIM and Memory card slot after Cap SIM/SD is opened.



Pre-Test Preparations


1.3 Test Enablers

These are items on the phone that are used during the test of the unit.

Note! The product supports only Nano SIM!


Front:

1. Notification LED.
2. Secondary Camera
3. Earphone / Speaker top port
4. Ambient Sensor, Proximity Switch
5. On/Off Key
6. Volume up/down Key
7. Camera key
8. Speaker bottom port / Microphone
9. USB slot
10. Strap hole (for WRT)




Back:

11. Main Wi-Fi / Bluetooth antenna area
12. Camera
13. LED Flash
14. Diversity / GPS antenna area
15. Audio jack
16. Second Wi-Fi antenna area
17. Nano SIM and Memory card slot
18. NFC area
19. Secondary Microphone



- A. Back key
- B. Home key
- C. Task key
- D. Menu key



Pre-Test Preparations

1.4 Software

1.4.1 Software update

1.4.1.1 Software version verification

Check the software version of the phone for fault verification. The latest improvements are found on the support pages under the support news: <http://www.sonymobile.com/global-en/support/>.

- Start up the phone
- Make sure the phone is in call setup.
- Press the following keypad combination: *##7378423##* (i.e. *##service##*)
- Select 'Service info'
- Select 'Software info'
- Check the software file revisions and, if needed, update as described below:

For more information, refer to 1220-1333: Generic Repair Manual - mechanical

1.4.1.2 Software version update

Mandatory first repair action!

Use the USB cable to connect with the Micro USB connector of the phone for this purpose!

Ensure the phone is powered off and proceed as follows:

- Open the Emma application and log in.
- Press and hold the volume down key on the phone, connect the phone to the USB cable and then release the volume down key.
- Select the appropriate service and follow the on-screen instructions.

Note: For phones with eMMC flash memory (built in "SD card" memory), the only service which erase this eMMC memory is Service's "Refurbish" and "Customize".

See also emma User Guide info.

http://software.sonymobile.com/emma/documents/emma_user_guide.pdf

(see "Service Types" and "Aspects of large files")

In Swap flow, when change a phone from Customer A to Customer B, always use the service Customization script.


2 Tests

2.1 Service Test Mode

Stamina mode needs to be turned off before entering Service Test Mode

Settings -> Power management -> STAMINA mode

- Start up the phone, go to call setup.
- Press the following keypad combination: *****7378423***** (i.e. *****service*****)



Service info: information about Model, Software, Simlock, Configuration (IMEI, bands, codec's), Factory charging, DTCP-IP, Firmware, WLAN Mac address etc.

Service settings: Do not use


Service test: Follow instruction below

Customization Settings: Do not use.

- Select 'Service tests'
- Select one of the tests and follow the test instructions as described below
- To stop the test and return to the 'Service tests' menu, press the Back key

For more information, refer to

1220-1333: Generic Repair Manual - mechanical



The following pictures will show a simplified basic phone for a general visualization of the service tests!

Tests


2.2 Service Tests

2.2.1 Keyboard & Switch

To return to the Service Test Menu, wait for 8 seconds.

Press all keys:

- **Back key:** notification on screen.
- **Home key:** will leave the Service tests menu.
- **Task navigation key:** taskbar will be shown, press Service Menu to return.
- **Menu key:** notification on screen.
- **Power key:** the screen will enter sleep mode, press the Power key one more time to wake up.
- **Volume up key:** notification on screen.
- **Volume down key:** notification on screen.
- **Auto Focus key (short press) / Camera key (long press):** notification on screen.




2.2.1 Touch Screen

Move a finger across the touch screen, a line will be drawn as it touches.

Check all area of the touch screen as indicated by the two lines.

Press the Back key to return to the Service Test Menu.




2.2.2 Display

Minor variations in the display's brightness and color may occur between phones.
If any tiny bright dots on the display are found, this indicates defective pixels which occur when individual dots have malfunctioned and cannot be adjusted.
Two defective pixels are considered to be acceptable.

Touch the display using a finger. With every touch, the display will show Nine test patterns of White, Gray, Black, Red, Green, Blue, Rainbow Colors, Cross-Line, TV Pattern on the full screen. Make sure that there are no missing segments and that the colors and contrast are OK.

Press the Back key to return to the Service Test Menu.




Tests: Service Tests

2.2.3 LED/Illumination

Check that the:

- Display Backlight illumination goes from low to high strength back to low again.
- Notification LED changes, showing four colors in the following sequence: green, green, blue, blue, off and red, red.


Press the Back key to return to the Service Test Menu.



2.2.4 Speaker

Do not use this test!

N/A, use Stereo Speaker test below.




2.2.5 Stereo speaker

Do not hold the unit close to your ear during this test!

Make sure that the sound from the speaker port at top and bottom are emitted loud and clear and that the test include maximum volume.

Press Volume up/Volume down key to adjust speaker volume.

Press Back key to return to Service Test Menu.




Tests: Service Tests

2.2.6 Earphone

Make sure that the sound from the earphone port is emitted loud and clear and the test includes maximum volume.

Press the volume up/volume down key to adjust the earphone volume.

Press the Back key to return to the Service Test Menu.




2.2.7 Microphone

The previous 'Stereo Speaker' test must have been successfully carried out before doing this test!


The phone will start to record and after approximately ten seconds the sound is played back through the speaker.

Step 1: Speak into the microphone during the 'Microphone Recording' phase.



Step 2: Check the quality by listening to the recording from the speaker during the 'Playing recorded sound' phase at maximum volume.

Press the Back key to return to the Service Test Menu.



Tests: Service Tests

2.2.8 Secondary Microphone

The previous 'Stereo Speaker' test must have been successfully carried out before doing this test!




The phone will start to record and after approximately ten seconds the sound is played back through the speaker.

Step 1: Speak into the secondary microphone during the 'Microphone Recording' phase.

Step 2: Check the quality by listening to the recording from the speaker during the 'Playing recorded sound' phase at maximum volume.

Press the Back key to return to the Service Test Menu.

Note! Covering the secondary microphone hole accidentally will greatly affect voice quality when making a call by using the hands free function mode. Refer to Test Enablers for the secondary microphone location.



2.2.9 Vibrator

Press the Menu key or side keys to start the vibrator test. It is possible to modify the duration of this test.

Press the Back key to return to the Service Test Menu.

Tests: Service Tests

2.2.10 Camera


Minor variations in image appearance may occur between phones, but is not uncommon and should not be regarded as an indication of a defective camera module!

Aim the camera (located at the back of the phone) at an object and check the quality of the image shown in the display.

Touch the screen to take picture and preview the photo's auto focus quality.

Photos are taken but not saved during this test!

Press the Back key to return to the Service Test Menu.




Only symbolic view

2.2.11 Secondary Camera

Minor variations in image appearance may occur between phones, but is not uncommon and should not be regarded as an indication of a defective camera module!

Aim the camera (located in front of the phone) at an object and check the quality of the image shown in the display.

Press the Back key to return to the Service Test Menu.




Only symbolic view

2.2.12 Flash LED

Check the Flash LED at the back side of phone whether it's turned on.

Press Back key to return to Service Test Menu.



Only symbolic view


Tests: Service Tests

2.2.13 Antenna RX Diversity

N/A.

Do not use this test!

Press the Back key to return to the Service Test Menu.



2.2.14 Bluetooth


During this test, the distance between the phone and the target Bluetooth device must be 1.5 to 5 meters!
Make sure the target Bluetooth device is enabled and visible always!

The Bluetooth test will be done in following sequences:
 Step 1: Enable Bluetooth; wait 4-5 seconds, shows OK;

There is a permission request, select 'Yes'.


Step 2: Searching;

Step 3: Show the Device Found list;



Step 4: Select the Target Bluetooth Device,
 Step 5: Check the Pairing PIN code on both Target Bluetooth Device and unit, press Pair on both, when succeeded, it shows "Test Complete".

Press Back key to return to Service Test Menu.




Only symbolic view

Tests: Service Tests

2.2.15 WLAN

Make sure there's a WLAN network before performing this test.

The WLAN test will be done in following sequences:
 Step 1: Enable WLAN; wait 4-5 seconds, shows OK;
 Step 2: Searching;
 Step 3: Access points found list;
 Step 4: Select the Target WLAN network, and type the password to get connected;
 Step 5: Enter a web address (e.g. Google.com);
 Step 6: When connection succeed, it shows 'Test Complete'.
 Press the Back key to return to the Service Test Menu.




2.2.16 NFC

A NFC SIM card 4FF should be inserted in the phone before the start of this test!

The NFC test will be done in following sequences:
 Step 1: Select 'NFC';
 Step 2: Select 'NFC Diag Test';
 Step 3: After 'Tag Reading...Enabled' can be seen on the display, bring a NFC Tag close to NFC icon in the middle of the Panel Rear.
 Step 4: When Tag is identified, a sound will be made and an OK message will be displayed.

Press the Back key two times to return to Service Test Menu.




2.2.17 GPS

Enter the GPS Location Test and wait for the GPS location data.

Press the Back key to return to the Service Test Menu.

For GPS testing, refer to 1220-1333: Generic Repair Manual – mechanical




Tests: Service Tests

2.2.18 Compass

Do the test with hand movements as shown in the phone, and then check the actual direction with measured Yaw value.

(Yaw: 0=North, 90=East, 180=South, 270=West)


Press the Back key to return to the Service Test Menu.



2.2.19 Accelerometer

The accelerometer test displays the actual position of the phone as a 3D coordinate X: Y: Z.


Press the Back key to return to the Service Test Menu.



By tilting the phone in various directions, the X: Y: Z values will change in size and polarity depending on the angle and direction as shown in the adjacent picture.

Check by tilting the phone that the X: Y: Z values shown in the display are in accordance with the tilting shown in the picture.

Press the Back key to return to the Service Test Menu.




Tests: Service Tests

2.2.20 Gyroscope

The gyroscope test displays the actual position of the phone as a 3D coordinate X: Y: Z.

Check by moving the phone that the X: Y: Z values shown in the display are in accordance with the moving.


Press the Back key to return to the Service Test Menu.



Check 'Gravity Values' 'Linear Acceleration Values' 'Rotation Vector Values' and 'Gyroscope Values' by moving the phone:

'Gravity Values' can be refer to Accelerometer;
'Linear Acceleration Values' and 'Rotation Vector Values' are in accordance with the action shown in the picture.
'Gyroscope Values' are updated while moving the phone.


Press the Back key to return to the Service Test Menu.



2.2.21 Ambient Light Sensor

The Ambient light test states a value. The value should increase when the window gets more light and decrease when the window gets less light.

Press the Back key to return to the Service Test Menu.



Tests: Service Tests


2.2.22 Proximity switch

The previous 'Stereo Speaker' test should have been successfully carried out before doing this test!
Make sure the phone is not in 'silent mode' before performing this test.

When entering into the test, the screen shows 'Proximity switch OFF' and a tone is emitted.

When covering the proximity switch area, the screen will show 'Proximity switch ON' with a different type of tone.

Press the Back key to return to the Service Test Menu.




2.2.23 Hall Element Test

Enter this test and press power key to enter sleep mode!

Put the magnet beneath the Secondary camera, remove the magnet, the phone will wake up.

Press the Back key to return to the Service Test Menu.




2.2.24 Pressure Sensor

The Pressure Sensor test will check the atmospheric pressure around the phone and states a value. When you put the phone on the floor, read the value. When you raise the phone up as high as you can, the value should decrease about approx 0.2 to 0.3 Millibar.

The value shouldn't be static.

Press the Back key to return to the Service Test Menu.




Tests: Service Tests

2.2.25 Real time clock

During the actual test the text 'Real time clock' is displayed, and then followed by a message stating whether the test was OK or not.


Press the Back key to return to the Service Test Menu.



2.2.26 Total call time (E6553)

The total call time is displayed in the format HHHH:MM:SS (hours: minutes: seconds).


Press the Back key to return to the Service Test Menu.



2.2.27 Total call time (E6533)

The total call time of SIM Card 1 and SIM Card 2 are displayed in the format HH:MM:SS (hours: minutes: seconds).

Press the Back key to return to the Service Test Menu.



Tests: Service Tests


2.2.28 Storage

Memory Storage status:

A memory card should be inserted in the phone and attach USB Adaptor between phone and a USB disk before starting this test.

- Internal Mass Storage is 'Inserted/Mounted' as shown on the screen.
- External Storage (SD Card) is 'Inserted/Mounted' as shown on the screen.
- The USB Host Mass Storage is 'Inserted/Mounted' as shown on the screen.

Press the Back key to return to the Service Test Menu.




2.2.29 Security

The DRM keys are shown in the display.

There may be different content shown based on different market software versions.

Press the Back key to return to the Service Test Menu.




2.2.30 FM Radio

Verify that the phone can detect a radio station:

Connect a headset and then set your local radio station in Hz.

Verify that the reception and sound quality is normal.

Press the Back key to return to the Service Test Menu.



Tests: Service Tests

2.2.31 Verify certificates


When entering the test, five information categories will be shown:

Test: Media, Application, Shared, Platform

Live: Application.

Do not use this test!


Press the Back key to return to the Service Test Menu.




2.2.32 TV-Out Test

MHL adapter, HDMI Type A Cable, charger and TV should be connected with the phone before the start of this test!

Step 1: Attach cable between phone and TV-Out as shown in picture;



MHL TV Out is turned on after connection.




Tests: Service Tests

Step 2: Press 'Play Video'.

Receive a test tone and a red-green-blue test picture in the TV-Out Monitor and phone.

Note: If the TV-Out Monitor doesn't automatically identify the picture, the Monitor may require setting the TV-Out port chosen as source manually in the Monitors menus.




Only symbolic view

Step3: Press 'Chess board pattern' to do the same test as the 'Play video'.

Step4: Press 'Gray ramp pattern' to do the same test as the 'Play video'.

Press the Back key to return to the Service Test Menu.




Tests: Service Tests

2.2.33 WLAN Antenna TX/RX

N/A

Do not use this test!

Press the Back key to return to the Service Test Menu.



Tests: Manual Tests

2.3 Manual Tests

2.3.1 SIM test (E6553)

Verify that the phone can detect a SIM card:

Step 1: Insert a SIM card, and start the phone;


If the SIM card is detected by the phone, the start-up procedure will continue.

Step 2: The operator's name is displayed at the top left corner of the locked screen.

If not detected, the message 'No SIM card-Emergency call only' will be displayed instead.

If operator is not detected, the message 'No service' will be displayed instead.

Press Back key to return to Standby Menu.



2.3.2 SIM test (E6533)

Verify the phone can detect a SIM card 1 and a SIM card 2:

Step 1: Insert a SIM card 1 and a SIM card 2, and start the phone; If the SIM card 1 and SIM card 2 is detected by the phone, the start-up procedure will continue.

Step 2: The the SIM card 1 and SIM card 2 operator name will be displayed at the top left corner of the locked screen by turns.


If SIM card is not detected, the message 'No SIM card-Emergency call only' will be displayed instead. If operator is not detected, the message 'No service' will be displayed instead.

Press Back key to return to Standby Menu.



2.3.3 Data Communication test

- Connect a USB cable from a computer to the started phone.
- Verify that Data Communication works by transferring a file from Computer to phone
- Erase the file




Tests: Manual Tests

2.3.4 Audio Jack test

Connect a Sony Noise canceling headset
(see www.sonymobile.com go to the product and then Accessories for applicable headset)

Repeat the test of "Stereo Speaker", "Earphone" and "Microphone".


Make sure that the sound to and from Headset is emitted loud and clear and that the units Notification panel at the top show "Noise canceling icon show when you attach the headset.



Drag the status bar down to open the notification panel
Tap the Noise canceling on/off menu and enter the Noise canceling menu (you can also open it via Settings/Sound & notification/Accessory settings)

Turn on and off the switch in the upper right corner of the screen, you should hear a faint noise in the Headset at maximum volume.


Remove the Sony Noise canceling headset and press task key and chose the Service test again.



Connect a Sony CTIA headset (with microphone).
(see www.sonymobile.com go to the product and then Accessories)

Repeat the test of "Stereo Speaker", "Earphone" and "Microphone".

Make sure that the sound to and from Headset is emitted loud and clear.



Only symbolic view

Tests: Manual Tests

2.3.5 Charging (Charger or Computer)

2.3.5.1 Charging via USB (Charger or Computer)

Verify that the phone can charge the battery by a USB port:



Ensure that no computer application, such as PC Suite or Emma, is active!

Do not start the phone.

Connect a USB cable from a computer or charger to the phone.

Verify that the phone is being charged by the notification LED and Battery icon in the display can take up to 10 min before LED starts.

Remove the USB cable from the connector and verify that the Notification LED (see 1.3 Test Enablers) and Battery icon no longer indicates charging.



The Notification LED (see 1.3 Test Enablers) colour status is depended on battery remaining capacity:


- Red: Battery level is between 1% and 10%;
- Orange: Battery level is between 11% and 89%;
- Green: Battery is between 90% and 100%;

Tests: Manual Tests


If above fails, perform below Diagnostic battery / Charging Status check.

Perform a force shut down by pressing the OFF button next to SIM holder (for 10 seconds), as shown in picture, until the unit vibrates three times then release the button. Then the phone will shut down.

If you do not get any vibration and you can continue to press the HW reset, then after 2 minutes (120s) the phone will perform a very deep HW reset without any notification! This can solve some rare cases without having to open the unit and re-connect the battery connector.



Diagnostic Battery / Charging Status



The picture in above flow chart is only symbolic view.

Tests

2.3.6 Battery Test

If bad battery performance or capacity problem is claimed, the battery and charging function can be tested by using an application designed for this purpose.

By using this application the battery is tested in a fast and controlled environment.

This is especially convenient when units with embedded batteries should be checked, to avoid unnecessary work to disassembly the unit to access the battery.

This test is designed to identify a faulty battery or a hardware issue in the unit or with the charger. The guide will describe different procedures depending on the battery level when the battery test is initiated.

The test is downloaded to the unit using cable and executed.



The test is available in CSPN at Level: Mechanical,

Title: **Sony Mobile Repair Application 1289-2983**

Unzip this file, where you find the application, installation and user guide content.

Installation / un-installation and log reading are now included in Sony Mobile Repair Application 1289-2983.

Error messages are described in the user guide for the Sony Mobile Battery test.



Tests

2.3.7 Network Test

This test can only be performed if the phone has got an activated Nano SIM card (no Test Nano SIM) and an available network signal!

There are different versions of the test depending on whether a LTE, UMTS network is available or not!

If a LTE or UMTS network is available, the network test has to be done separately for GSM, UMTS or LTE!

2.3.7.1 On-the-air call to mobile

GSM

Go to the Setting app:

Settings ⇒ More.. ⇒ Mobile networks ⇒ Preferred Network Mode ⇒ GSM only

Ensure that the Network Status icon show signal strength and show no symbol or E at the top of the display.

To verify the radio functions (GSM) of the phone, follow the 'Procedure (GSM & UMTS)' below.

This test is applicable for E6553 and E6533 (SIM Card 1 and SIM Card 2, and the E6533 SIM Card 2 only support GSM and its Network mode cannot be selected).

UMTS (if available)

Go to the Setting app:

Settings ⇒ More.. ⇒ Mobile networks ⇒ Preferred Network Mode ⇒ WCDMA only

Ensure that the Network Status icon show signal strength and show 3G or H+ (HSPA) at the top of the display.

To verify the radio functions (UMTS) of the phone, follow the 'Procedure (GSM & UMTS)'.

This test is applicable for E6553 and E6533 SIM Card 1.

LTE (if available)

Go to the Setting app:

Settings ⇒ More.. ⇒ Mobile networks ⇒ Preferred Network Mode ⇒ LTE (preferred)/WCDMA/GSM

Ensure that the Network Status icon show signal strength and show LTE at the top of the display.

To verify the radio functions (LTE) of the phone, download data package by for ex. Accessing the web.

This test is applicable for E6553 and E6533 SIM Card 1.

Network Type can be checked in *Settings ⇒ About phone ⇒ Status ⇒ Mobile network type*

2.3.7.2 Procedure (GSM & UMTS)

Step 1: Set up a call from a landline phone (PSTN).


Step 2: Check that there is a ring signal.

Step 3: Check that the display backlight illuminates.

Step 4: Answer the call and check the sound quality in both phones.

Step 5: Adjust the volume up and down with the side keys and verify that the sound level is altered.

Step 6: End the call and check that the elapsed time is displayed and that the termination is done properly.



Only symbolic view

3 Revision History

Rev.	Date	Changes / Comments
1	2015-May-27	Initial Release