



Sony Ericsson

# Test Instructions

- mechanical -



*Vivaz pro*  
*U8i, U8a*



## CONTENTS

<b>1</b>	<b>Pre-Test Preparations .....</b>	<b>3</b>
1.1	Hardware .....	3
1.1.1	Liquid Intrusion indicator inspection .....	3
1.2	Software.....	4
1.2.1	Software update .....	4
1.2.2	Phone lock reset .....	4
<b>2</b>	<b>Tests .....</b>	<b>5</b>
2.1	Service Test Mode.....	5
2.2	Service Tests.....	6
2.2.1	Display .....	6
2.2.2	Camera.....	6
2.2.3	Touch screen.....	7
2.2.4	Illumination/LED.....	7
2.2.5	Keys .....	7
2.2.6	Vibrating alert.....	8
2.2.7	Speaker .....	8
2.2.8	Microphone.....	8
2.2.9	External Memory card.....	9
2.2.10	FM radio .....	9
2.2.11	Security.....	9
2.2.12	Real time clock.....	10
2.2.13	Accelerometer .....	10
2.2.14	GPS .....	11
2.2.15	WLAN .....	11
2.2.16	Bluetooth .....	11
2.2.17	Total call time .....	12
2.2.18	Ambient light .....	12
2.2.19	Ear Speaker .....	13
2.3	Manual Tests .....	14
2.3.1	SIM .....	14
2.3.2	Battery charging .....	14
2.4	Network Test .....	15
2.4.1	On-the-air call to mobile (no UMTS network available) .....	15
2.4.2	On-the-air call to mobile (UMTS network available).....	15
<b>3</b>	<b>Revision History .....</b>	<b>16</b>

*For general information about test procedures, refer to  
1220-1333: Generic Repair Manual - mechanical*



# 1 Pre-Test Preparations

## 1.1 Hardware

### 1.1.1 Liquid Intrusion indicator inspection

Before starting any tests the liquid intrusion indicator has to be checked.

The indicator is located as shown in this picture after having the battery cover removed.

If not affected by liquid, proceed to the 'Pre-Test Preparation' below.

If affected (red color) - handle the phone according to your local directives.





## Pre-Test Preparations

### 1.2 Software

#### 1.2.1 Software update

##### 1.2.1.1 Software version verification

Check the software versions of the phone to establish whether a software version update is needed:

- Start up the phone and press the Green (Send/Call) key and Red (End) key as follows:
- Pressing Key Sequences: Red Green Red Red Green Red
- select 'Service information'
- select 'Software information'
- check the software file revisions and, if needed, update as described below

**For more information, refer to 1220-1333: Generic Repair Manual - mechanical**

##### 1.2.1.2 Software version update

**Use the EC700 Micro USB to USB cable for this purpose!**

**Do not use the SEPI equipment!**

Install a fully charged battery, ensure the phone is powered off and proceed as follows:

- Open the Emma application and log in
- Press and keep the "Green"(Send/Call) key down on the phone, connect the phone to the USB cable and release the "Green"(Send/Call) key
- Select the appropriate service and follow the on-screen instructions

#### 1.2.2 Phone lock reset

Install a fully charged battery, ensure the phone is powered off and proceed as follows:

- Open the Emma application and log in
- Press and keep the "Green"(Send/Call) key down on the phone, connect the phone to the USB cable and release the "Green"(Send/Call) key
- When prompted, select the 'U5 Phone Lock Reset' service.
- 'Success' will be displayed on the USB icon when the phone lock code has been reset to '0000'.



## 2 Tests


### 2.1 Service Test Mode

**All service tests except Keys, WLAN, GPS and Bluetooth can be carried out without a SIM card!**

Start up the phone and enter the service menus:

- press the Green (Send/Call) key and Red (End) key in the following order: Red Green Red Red Green Red
- select 'Service tests'
- select one of the tests and follow the test instructions as described below
- to stop the test and return to the 'Service tests' menu, press the End(Red) key.

**For more information, refer to  
1220-1333: Generic Repair Manual - mechanical**



**The pictures to follow will show a simplified basic phone  
for a general visualization of the service tests!**




## Tests

### 2.2 Service Tests

#### 2.2.1 Display

**Minor variations in display brightness and colour may occur between phones.**  
**There may be tiny bright dots on the display, so called defective pixels and occur when individual dots have malfunctioned and can not be adjusted.**  
**Two defective pixels are considered to be acceptable.**

The display will show different test patterns.  
Make sure that there are no missing segments and that the colours and contrast are OK.




#### 2.2.2 Camera

**Minor variations in image appearance may occur between phones, but is not uncommon and should not be regarded as an indication of a defective camera module!**

Aim the camera (located back of the phone) at an object and check the quality of the image shown in the display.


**Photos is taken but not saved during this test!**



## Tests: Service Tests

### 2.2.3 Touch screen


Move your finger across the display, a line will be drawn as you touch the display.



### 2.2.4 Illumination/LED

Check that the:

- **Display light** is changed in three different sequences Bright/Normal and Off
- **Keyboard light** are turned on and off
- **LED 1,2** (Notification LED(located left side of the phone beside the USB connector) and Tally LED (located back of the phone beside the Camera)) are turning on and off
- **Flash LED (located back of the phone)** is activated for a period of time after you press "Flash LED" on the screen




### 2.2.5 Keys

**Insert SIM card before performing this test**

Press all keys:

- Send(call) key, menu(application) key and end key
  - Volume keys, camera keys, and on/off key of the phone
- Check that each pressure is confirmed in the display under last key pressed.



## Tests: Service Tests

### 2.2.6 Vibrating alert

Press the On key to start the vibrator test and Off key to end the test.




### 2.2.7 Speaker

**Do not hold the phone close to your ear during this test!**

Make sure that the sound from the speaker port on the left side of the phone is emitted loud and clear.

Press Volume up/Volume down key to adjust ear speaker volume.

Press Back key to return to ServiceTests Menu.




### 2.2.8 Microphone

**The previous test, 'Speaker', should have been successfully carried out before doing this test!**

The phone will start to record and after approximately seven seconds the sound is played back through the Speaker.

Speak into the microphone during the 'Microphone Recording' phase.

Check the quality by listening to the recording from the speaker during the 'Microphone Playback' phase.








## Tests: Service Tests

### 2.2.9 External Memory card

***A memory card should be inserted in the phone before the start of this test!***

The phone should detect that the memory card is inserted.




### 2.2.10 FM radio

***A Portable Hands-Free (PHF) has to be connected to the Audio Jack connector prior to this test!***


Use the Touch window to enter the frequency of an FM station known to be good regarding reception.

Listen to the FM station and verify that the sound quality is as good as can be expected.



### 2.2.11 Security

The DRM keys are shown in the display





## Tests: Service Tests


### 2.2.12 Real time clock

During the actual test the text 'Real time clock test' is displayed, then followed by a message stating whether the test was OK or not.




### 2.2.13 Accelerometer

The accelerometer test displays the actual position of the phone as a 3D coordinate X:Y:Z



By tilting the phone in various directions, the X:Y:Z values will change in size and polarity depending on angle and direction as shown in the adjacent picture.

Check by tilting the phone that the X:Y:Z values shown in the display are in accordance with the tilting shown in the picture.






## Tests: Service Tests

### 2.2.14 GPS

**Insert SIM card before performing this test**


**For GPS testing, refer to  
1220-1333: Generic Repair Manual - mechanical**



### 2.2.15 Wi-Fi

**Insert SIM card before performing this test**

The Wi-Fi test automatically detects if there are any WLAN (Wireless Local Area Network) connection. Then press back and you will get if the Wi-Fi is ok or not




### 2.2.16 Bluetooth

**Insert SIM card before performing this test**

**During this test, the distance between the phone and the other Bluetooth device must be 1.5 to 5 meters!**

The Bluetooth test display if Bluetooth is ok or not and which devices it has detected.





## Tests: Service Tests


### 2.2.17 Total call time

The total call time is displayed in the format HH:MM:SS (hours:minutes:seconds).



### 2.2.18 Ambient light

The Ambient light test states a value. Look that the value should be higher when the Window get more light and should decrease when the window gets less light.





## Tests: Service Tests


### 2.2.19 Ear Speaker

***Do not hold the phone close to your ear during this test!***

Make sure that the sound from the Ear Speaker (Receiver) port on the front top of the phone is emitted loud and clear.

Press Volume up/Volume down key to adjust ear speaker (Receiver) volume.

Press Back key to return to ServiceTests Menu.




### 2.2.20 Keyboard layout

Keyboard layout specification.

Visual check if it's in the following order : "QWERTY"

Press Back key to return to ServiceTests Menu.






## Tests

### 2.3 Manual Tests

#### 2.3.1 SIM

Verify that the phone can detect a SIM card:

- insert a SIM card, install a battery and start the phone
- if the SIM card is detected by the phone, the start-up procedure will continue
- if not detected, the message 'Insert SIM card' will be displayed




#### 2.3.2 Battery charging

##### 2.3.2.1 Charging by wall charger

Verify that charging of the phone functions properly:

- install a battery but do not start the phone
- connect a wall charger to the Micro USB connector
- verify that the display shows that the phone is being charged
- remove the charger from the Micro USB connector and verify that the display no longer indicates charging




##### 2.3.2.2 Charging via USB

Verify that the phone can charge the battery via a USB port:

**Ensure that no computer application, such as PC Suite or Emma, is active!**

- install a battery but do not start the phone
- connect a USB cable from a computer to the Micro USB connector
- verify that the display shows that the phone is being charged
- remove the USB cable from the Micro USB connector and verify that the display no longer indicates charging





## Tests

### 2.4 Network Test

**This test can only be performed if the phone has got an activated SIM/USIM card (no Test SIM/USIM) and an available network signal!**

**There are two versions of the test depending on whether a UMTS network is available or not!**


**If a UMTS network is available, the network test has to be done separately for GSM and UMTS!**

#### 2.4.1 On-the-air call to mobile (no UMTS network available)

To verify the radio functions (GSM) of the phone, follow the '2.4.1.1 Procedure' below

##### 2.4.1.1 Procedure

1. Set up a call from a landline phone (PSTN)
2. Check that the ring signal goes on
3. Check that the display backlight illuminates
4. Answer the call and check the sound quality in both phones
5. Adjust the volume up and down with the side key and verify that the sound level is altered
6. End the call and check that the elapsed time is displayed and that the termination is done in a proper way



#### 2.4.2 On-the-air call to mobile (UMTS network available)

##### GSM

Go to the phone menu and set:

*Settings* ⇒ *Connectivity* ⇒ *Networks* ⇒ *Network mode* ⇒ *GSM*

To verify the radio functions (GSM) of the phone, follow the '2.4.1.1 Procedure' above.

##### UMTS

Go to the phone menu and set:

*Settings* ⇒ *Connectivity* ⇒ *Networks* ⇒ *Network mode* ⇒ *UMTS*

Switch off the phone and then start it up again to enable search for an available UMTS signal. Ensure that the UMTS/3G icon now is visible at the top of the display.

To verify the radio functions (UMTS) of the phone, follow the '2.4.1.1 Procedure' above.



## 3 Revision History

Rev.	Date	Changes / Comments
1	2010-May-20	Initial release