




Vibrator





M2


| | | | |
|--|-------------------------|-------|---------|
| Sony Ericsson - W205, W205a : AAB-1880011-BV-W205a | | | |
| Title | | | |
| 03_M2 Vibrator | | | |
| Size | Document Number | | Rev |
| A4 | 2/0362-14/FCP1190806/2 | | AP |
| Date: | Tuesday, April 14, 2009 | Sheet | 3 of 11 |





| | | | |
|--|-------------------------|------------------------|---------|
| Sony Briceon - W205, W205a : AAB-188011-BV-W205a | | | |
| 07_A1 | | | |
| Size | Document Number | 2/0362-14/PCP1190806/2 | |
| Rev | AP | | |
| Date | Tuesday, April 14, 2009 | Sheet | 7 of 11 |





| | | | |
|--|-----------------|------------------------|---------|
| Sony Ericsson - W205, W205a 1 AAB-1880011-BV-W205a | | | |
| 09_Keypad | | | |
| Rev | Document Number | 2/0362-14/PCD1190806/2 | |
| Rev | Version | 1 | Rev |
| Tuesday, April 14, 2009 | | Page | 9 of 11 |

