

Part List

- mechanical -



Xperia™ ZR

C5502, C5503,

CONTENTS

1 Part List 3

2 Revision History 9

1 Part List

The following parts are available for order in 'E-star'.



The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.

Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.

RLC, Reversed Logistic Classification column for replaced part handling,

(See the Spare Part Handling chapter in Mechanical/Generic Repair Manual 1220-1333).











Designation	Part No.	RLC	Part	Location
Adhesive Display	1268-4853	C		
Adhesive Panel Key Power	1272-3262	C		
Adhesive PBA Antenna	1272-4150	C		
Adhesive Speaker	1269-2215	C		
<u>Camera</u> Camera 13 MPixel	1267-8793	B		
Card Connector Tray	1261-4278	C		
<u>Cover Battery</u> Cover Battery Black Cover Battery Mint Cover Battery Pink Cover Battery White	1270-8000 1272-2052 1272-2050 1270-8166	B		

Designation	Part No.	RLC	Part	Location
<u>Cover Main</u> Cover Main Black Cover Main Mint Cover Main Pink Cover Main White	1273-3932 1273-3934 1273-3935 1273-3933	B		
Cushion 2nd MIC	1269-2237	C		
Cushion 3 x 3 mm	1272-2203	C		
Cushion 3 x 8 mm	1269-2238	C		
Cushion Mic	1269-2217	C		
Cushion Window	1270-7522	C		
<u>Display</u> Display 4.6 inch	1273-0461	A		
FPC PBA NFC	1269-1961	B		
FPC Relay	1272-2670	B		

Designation	Part No.	RLC	Part	Location
FPC Top Compl	1268-5878	C		
Gasket 2nd MIC	1268-4876	C		
Gasket Chat Camera	1268-5535	C		
Gasket Key	1268-5072	C		
Gasket Key Cam	1271-0128	C		
Holder Side Keys	1268-5766	C		
<u>Key Camera</u> Key Camera Black Key Camera Mint Key Camera Pink Key Camera White	1268-5287 1270-8244 1270-8242 1270-8237	C		
Key Power	1268-5244	C		
<u>Key Volume</u> Key Volume Black Key Volume Mint Key Volume Pink Key Volume White	1268-5281 1270-8228 1270-8227 1270-8226	C		

Designation	Part No.	RLC	Part	Location
Label Mobile Phone	1268-5798	C		
Lightguide	1272-2196	C		
Lightguide Sheet	1270-6676	C		
Loudspeaker	1267-9538	C		
Net Speaker	1268-4877	C		
Nut	1268-9074	C		
Panel Key Power	1268-5293	C		
<u>Panel Side L</u> Panel Side L Black Panel Side L Mint Panel Side L Pink Panel Side L White	1270-8030 1272-2069 1272-2067 1270-8175	C		
<u>Panel Side R Bottom</u> Panel Side R Bottom Black Panel Side R Bottom Mint Panel Side R Bottom Pink Panel Side R Bottom White	1268-5308 1270-8262 1270-8261 1270-8259	C		

Designation	Part No.	RLC	Part	Location
<u>Panel Side R Top</u> Panel Side R Top Black Panel Side R Top Mint Panel Side R Top Pink Panel Side R Top White	1268-5305 1270-8256 1270-8254 1270-8253	C		
PBA Antenna	1268-9013	B		
RF Coax Cable	1269-3687	C		
<u>Screw 2.0</u> Screw Len:2.0 Diam:1.4 M	1271-7553	C		
<u>Screw 2.2</u> Screw Len:2.2 Diam:1.4 M	1269-3651	C		
<u>Screw 3.4</u> Screw Len:3.4 Diam:1.4	1270-7525	C		
<u>Screw 5.0</u> Screw Len:5.0 Diam:1.4	1269-3650	C		
Sheet Battery Side	1269-2235	C		
Sheet FPC Relay	1268-5771	C		

Designation	Part No.	RLC	Part	Location
Sheet Magnetic NFC	1272-2110	C		
Support Plate	1268-5524	C		
Washer Key Power	1274-4154	C		
Water Indicator	1255-4136	C		  

2 Revision History

Rev.	Date	Changes / Comments
1	2013-June-14	Initial release
2	2013-June-28	Added parts for Mint and Pink 1270-8227, 1270-8228, 1270-8242, 1270-8244, 1270-8254, 1270-8256, 1270-8261, 1270-8262, 1272-2050, 1272-2052, 1272-2067, 1272-2069, 1273-3934, 1273-3935.
3	2013-Nov-1	RLC added
4	2013-Nov-22	Typo corrected.