

## Repair Movies

- mechanical -



*Xperia™ C3 Dual*  
*S55t, S55u, D2502*

*Xperia™ C3*  
*D2533*

CONTENTS

1 Movies ..... 3

1.1 Disassembly ..... 3

1.2 Reassembly ..... 3

2 Revision History ..... 4

*To view the embedded repair movies in this document, Acrobat Reader version 8 (or later) and Flash Player version 8 (or later) must be installed on your computer.*

*For best picture quality, select “Actual size” or “100%” as zoom level in Acrobat Reader. To magnify while keeping an acceptable picture quality, increase the zoom level to 200%.*

*If the movies appear to be jerky or blurred when viewing on-line, this is probably caused by the connection speed being too slow. In that case, right-click with the mouse on the document name and select Save Target As to download the repair movie document for off-line viewing.*

*For general information about repair movies, refer to 1220-1333: Generic Repair Manual - mechanical*

## 1 Movies


### 1.1 Disassembly

- SIM Tray
- Back Cover Assy
- Ant Top Frame Assy
- 2nd Mic Rubber
- Main Camera
- Chat Camera
- Main PBA
- Core Unit label Tray
- Ant Speaker Bottom Frame Assy (a) and Display Frame Assy (b)



### 1.2 Reassembly

- Display Frame Assy (a) and Ant Speaker Bottom Frame Assy (b)
- Core Unit label Tray
- Main PBA
- Chat Camera
- Main Camera
- 2nd Mic Rubber
- Ant Top Frame Assy
- Back Cover Assy
- SIM Tray



## 2 Revision History

Rev.	Date	Changes / Comments
1	2014-Jul-18	Initial release
2	2014-Aug-08	Added D2533/D2502