

Repair Movies

- mechanical -



Xperia™ Z1 Compact
D5503, M51w

CONTENTS

1 Movies 3

1.1 Disassembly 3

1.2 Reassembly 3

2 Revision History 4

To view the embedded repair movies in this document, Acrobat Reader version 8 (or later) and Flash Player version 8 (or later) must be installed on your computer.

For best picture quality, select “Actual size” or “100%” as zoom level in Acrobat Reader. To magnify while keeping an acceptable picture quality, increase the zoom level to 200%.

If the movies appear to be jerky or blurred when viewing on-line, this is probably caused by the connection speed being too slow. In that case, right-click with the mouse on the document name and select “Save Target As” to download the repair movie document for off-line viewing.

For general information about repair movies, refer to 1220-1333: Generic Repair Manual - mechanical

1 Movies

1.1 Disassembly

D5503

The Disassembly is done to the following modules:

- Panel Rear Assy
- Battery
- Cover Rear
- Carrier Holder Speaker Assy
- Plate Label & SIM Tray
- Holder USB
- Display
- Main PBA & Frame Main Assy



1.2 Reassembly

D5503

The Re-assembly is done to the following modules:

- Main PBA & Frame Main Assy
- Display
- Holder USB
- Plate Label & SIM Tray
- Carrier Holder Speaker Assy
- Cover Rear
- Battery
- Panel Rear Assy



2 Revision History

Rev.	Date	Changes / Comments
1	2014-Jan-28	Released
2	2014-Jan-31	RTL Version
3	2014-Feb-03	Disassembly & Reassembly Chapter updated
4	2014-Feb-11	Added M51w
5	2015-Feb-25	Additional information added for disassembly sequence