

## Repair Movies

- mechanical -



*Xperia™ Z3+*  
*E6553*

*Xperia™ Z3+ Dual*  
*E6533*

CONTENTS

1 Movies ..... 3

1.1 Disassembly ..... 3

1.2 Reassembly ..... 4

2 Revision History ..... 5

To view the embedded repair movies in this document, Acrobat Reader version 8 (or later) and Flash Player version 8 (or later) must be installed on your computer.

For best picture quality, select “Actual size” or “100%” as zoom level in Acrobat Reader. To magnify while keeping an acceptable picture quality, increase the zoom level to 200%.

If the movies appear to be jerky or blurred when viewing on-line, this is probably caused by the connection speed being too slow. In that case, right-click with the mouse on the document name and select Save Target As to download the repair movie document for off-line viewing.


For general information about repair movies, refer to 1220-1333: Generic Repair Manual - mechanical

The movie is based on using E6553 model, the design differences between E6553 and E6533 are minor, therefore please refer to the Working Instruction (1295-7193) for detailed instruction.

## 1 Movies

### 1.1 Disassembly

- Tray Combo(E6553)/Tray Dual Nano SIM DS(E6533)
- Adhesive Battery C (a) and Panel Rear (b)
- Sheet Shade 3LED
- Main Camera
- Antenna Diversity
- Light Guide 3LED
- Chat Camera
- Main PBA
- Top Flex module
- Holder Jack
- Antenna WLAN
- RF Cable
- Vibrator (a) and Adhesive Vibrator (b)
- Adhesive Battery A (a) and Adhesive Battery B (b) and Battery (c)
- Cushion Battery Side
- Cushion Battery Bottom
- Spacer Battery
- Holder Vibrator & Sub PBA
- Plate speaker
- Loudspeaker & Cap Speaker Sub Assy
- Relay\_L Flex module (a) and Adhesive Shield FPC LCD (b)
- Sheet Conductive Relay U (a) and Relay\_U Flex module (b)
- Sheet Conductive Relay U (a) and Shield FPC LCD Sub Assy (b) and Display Frame Assy (c)



## Movies

### 1.2 Reassembly

- Display Frame Assy (a) and Shield FPC LCD Sub Assy (b) and Sheet Conductive Relay U (c)
- Sheet Conductive Relay U (a) and Relay\_U Flex module (b)
- Adhesive Shield FPC LCD (a) and Relay\_L Flex module (b)
- Loudspeaker & Cap Speaker Sub Assy
- Plate speaker
- Holder Vibrator & Sub PBA
- Spacer Battery
- Cushion Battery Bottom
- Cushion Battery Side
- Adhesive Battery A (a) Adhesive Battery B (a) and Battery (b)
- Adhesive Vibrator (a) and Vibrator (b)
- RF Cable
- Antenna WLAN
- Holder Jack
- Top Flex module
- Main PBA
- Chat Camera
- Light Guide 3LED
- Antenna Diversity
- Main Camera
- Sheet Shade 3LED
- Adhesive Battery C (a) and Panel Rear (b)
- Tray Combo(E6553)/Tray Dual Nano SIM DS(E6533)





## 2 Revision History

Rev.	Date	Changes / Comments
1	2015-May-27	Initial release