


## Part List

- mechanical -



*Xperia™ XA*

*F3111,F3112,F3113,F3115,F3116*

CONTENTS

1 Part List ..... 3

2 Revision History ..... 12













## 1 Part List

















The following parts are available for order in 'E-star'.

















The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.

Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.



















RLC, Reversed Logistic Classification column for replaced part handling, See the Spare part handling chapter in Mechanical/Generic Repair Manual (1220-1333).

Designation	Part No.	RLC	Part	Location
Adhesive Battery Cover Bottom	306Q1N10D00	C		
Adhesive Battery Cover Left	XXKS100997W	C		
Adhesive Battery Cover Right	XXKS100994W	C		
Adhesive Battery Cover Top	306Q1N10E00	C		
Adhesive Camera Key FPC	XXKS101002W	C		
Adhesive LCM Left Side	306Q1N10300	C		

Designation	Part No.	RLC	Part	Location
Adhesive LCM Right Side	306Q1N10400	C		
Adhesive Main Camera	306Q1N10M00	C		
Adhesive NFC	306Q1N10F00	C		
Adhesive Power_Volume Key FPC	XXKS101001W	C		
Adhesive Receiver	306Q1N10900	C		
Adhesive Side Deco Left	306Q1N10I00	C		
Adhesive Side Key FPC_A	XXKS101003W	C		
Adhesive Side Key FPC_B	XXKS101004W	C		











Designation	Part No.	RLC	Part	Location
Adhesive Sponge Front Camera	306Q1N10600	C		
Antenna Assy DIV/BT/WIFI/GPS Antenna Assy DIV/BT/WIFI/GPS F3111/F3112 Antenna Assy DIV/BT/WIFI/GPS F3113 Antenna Assy DIV/BT/WIFI/GPS F3115/F3116	78PA3700010 78PA3700020 78PA3700030	C		
Audio Jack Assy	78PA3200010	C		
Battery	1298-9239	C		
Battery Cover Assy Battery Cover Assy Black Battery Cover Assy White Battery Cover Assy Lime Gold Battery Cover Assy Rose Gold	78PA3000030 78PA3000010 78PA3000040 78PA3000020	B		
Cap SIM/SD Cap SIM/SD Black Cap SIM/SD Sliver Cap SIM/SD Lime Gold Cap SIM/SD Rose Gold	306JVY3602W 306JVY3601W 306JVY3603W 306JVY3604W	C		
Conductive Gasket Audio Jack	306A1N10800	C		
Conductive Gasket Main Camera Bracket	306AVY3605W	C		



















Designation	Part No.	RLC	Part	Location
Conductive Tape Front Camera	XXKS101016W	C		
Conductor Foil Battery Cover	306A1N10500	C		
Conductor Foil Front Camera	306AVY3601W	C		
Conductor Tape Sub PBA	306A1N10600	C		
CU Label	XXKS100968W	C		
CU Label Tray	306L1N10A00	C		
<u>Display Cover Assy</u> Display Cover Assy Black Display Cover Assy White Display Cover Assy Lime Gold Display Cover Assy Rose Gold	78PA3100010 78PA3100030 78PA3100020 78PA3100050	A		
Film Kapton Audio Jack	306L1N10800	C		



Designation	Part No.	RLC	Part	Location
Film Mylar Audio Jack FPC	306L1N10900	C		
Film Mylar Battery Left	306L1N10600	C		
Film Mylar Battery Right	306L1N10700	C		
Front Camera	78PA3400020	B		
<u>Key Camera</u> Key Camera Black Key Camera Sliver Key Camera Lime Gold Key Camera Rose Gold	31251N10E00 31251N10D00 31251N10F00 31251N10G00	C		
<u>Key Power_Volume</u> Key Power_Volume Black Key Power_Volume Sliver Key Power_Volume Lime Gold Key Power_Volume Rose Gold	31251N10A00 31251N10900 31251N10B00 31251N10C00	C		
<u>Main Antenna Speaker Assy</u> Main Antenna Speaker Assy F3111/F3112 Main Antenna Speaker Assy F3113 Main Antenna Speaker Assy F3115/F3116	78PA3600010 78PA3600020 78PA3600030	C		
Main Camera	78PA3400010	B		
Main Camera Lens Assy	78PA3900010	C		

Designation	Part No.	RLC	Part	Location
NFC Antenna	2300VY3602W	C		
Receiver	2240000027W	C		
RF Cable	7320000131W	C		
Rubber 2nd MIC	302AVY3601W	C		
Rubber Audio Jack BTB Connector	302AVY3605W	C		
Rubber Front Camera BTB Connector	302AVY3603W	C		
Rubber LCM TP BTB Connector	302AVY3604W	C		
Rubber Main Camera BTB Connector	302AVY3608W	C		
Rubber Main MIC	302AVY3602W	C		



Designation	Part No.	RLC	Part	Location
Rubber PL Sensor	302A1N10200	C		
Rubber Sub PBA BTB Connector	302AVY3607W	C		
Screw Cross M1.2 L2.5 Black	27000000X00	C		
Screw TORX M1.2 L1.8 Silver	27000000V00	C		
Side Deco Left Side Deco Left Black Side Deco Left Silver Side Deco Left Lime Gold Side Deco Left Rose Gold	251K1N10200 251K1N10100 251K1N10300 251K1N10400	B		

Designation	Part No.	RLC	Part	Location
<u>Side Deco Right</u> Side Deco Right Black Side Deco Right Silver Side Deco Right Lime Gold Side Deco Right Rose Gold	254FVY3606W 254FVY3603W 254FVY3609W 254FVY3613W	C		
Side Key FPC Assy	78PA3500010	C		
SIM Tray Dual (only applicable for F3112, F3116)	305AVY3602W	C		
SIM Tray Single (only applicable for F3111, F3113, F3115)	305A1N10100	C		
Sponge Main Camera BTB Connector	303MVY3606W	C		
Sponge Speaker_Main MIC	303M1N10700	C		
<u>Sub PBA Assy</u> Sub PBA Assy F3111/F3112 Sub PBA Assy F3113/F3115/F3116	78PA3300010 78PA3300020	C		
Washer Nylon Screw	306G1N10100	C		
Water Intrusion Label	82KB600001W	C		

Designation	Part No.	RLC	Part	Location
Water Intrusion Label Rectangle	82VY580001W	C		

## 2 Revision History

Rev.	Date	Changes / Comments
1	2016-Jun-01	Initial release