

Mandatory replacement part	Part Number	Refurbish	Battery	Battery Cover Assy	Copper Foil Battery Cover	CU Label Tray	Display Cover Assy	Div Antenna Assy	Front Camera	Key Power_Volume	Main Antenna Speaker Assy	Main Camera	Main Camera Lens	Main PBA_Sub PBA FPC	NFC Antenna	Receiver	RF Cable	Sub PBA Assy	Main PBA
Adhesive Div Antenna Assy_Back	306Q1OI0C00	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
Adhesive Div Antenna Assy_Front	306Q1OI0A00	1				1	1	1	1	1		1				1			1
Adhesive Main Antenna Speaker Assy	306Q1OI0500	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
Adhesive Main PBA_Sub PBA FPC	XXKS101111W	1					1												
Adhesive Receiver	306Q1OI0700															1			
Adhesive Rubber Front Camera	306Q1OI0G00					1			1	1		1				1			1
Adhesive Rubber Main Camera	302A1OI0700											1							
Adhesive Sub PBA	306Q1OI0H00	1					1				1			1			1		
Battery	1298-9239	1					1							1					
Battery Cover Assy Black	78PA4200020																		
Battery Cover Assy White	78PA4200010	1																	
Bracket Main Camera	305A1OI0300																		
Cap SIM/SD Black	306J1OI0100																		
Cap SIM/SD White	306J1OI0200																		
Conductive Gasket Main Camera Bracket	30681OI0200																		
Conductive Gasket Sub PBA	30681OI0400																		
Conductor Foil Front Camera	306F1OI0500								1										1
Copper Foil Battery Cover	306F1OI0C00																		
CU Label	XXKS100968W	1				1									1				1
CU Label Tray	306L1OI0D00																		
Display Cover Assy Black	78PA4100020																		
Display Cover Assy White	78PA4100010	1																	
Div Antenna Assy	78PA4400010																		
Film Mylar Battery	306L1OI0C00	2	2				2							2					
Front Camera	7651000D00																		
Key Power_Volume Black	31251OI0100																		
Key Power_Volume White	31251OI0200																		
Main Antenna Speaker Assy	78PA4300010																		
Main Camera	78PA4600010																		
Main Camera Lens	254S1OI0100																		
Main PBA_Sub PBA FPC	78PA4500010																		
NFC Adhesive	306Q1OI0E00		1		1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
NFC Antenna	2300CY33200				1														
Receiver	2240000078W																		
RF Cable	73200000C00																		
Rubber 2nd MIC	302A1OI0400																		
Rubber Front Camera BTB Connector	302A1OI0200								1										
Rubber LCM TP BTB Connector	302A1OI0600	1				1	1			1		1		1		1			
Rubber Main Camera BTB Connector	302A1OI0300											1							
Rubber Sub PBA BTB Connector	302A1OI0500	1					1							1					
Screw TORX M1.6 L3 Black	2700000108W	7				3	7	3	3	3	4	3		4		3	4	4	3
SIM Tray Single	305A1OI0400																		
Sponge Front Camera BTB Connector	303M1OI0B00								1										1
Sponge Indicator	303M1OI0800																		
Sponge Main Camera BTB Connector	303M1OI0900											1							
Sponge Main MIC	303M1OI0A00																		
Sponge Speaker_Main MIC	306M1OI0B00																		
Sub PBA Assy F3311	78PA4000020																		
Sub PBA Assy F3313	78PA4000010																		
Water Intrusion Label	82KB600001W																		
Water Intrusion Label Rectangle 2.5*1.3m	82VY520001W																		