

Part List

- mechanical -



Xperia™ XA1 Ultra
G3221, G3223

Xperia™ XA1 Ultra Dual SIM
G3212, G3226

CONTENTS

1 Part List 3

2 History 12













1 Part List

The following parts are available for order in 'E-star'.






The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.











Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.

RLC, Reversed Logistic Classification column for replaced part handling, See the Spare part handling chapter in Mechanical/Generic Repair Manual (1220-1333).



















Designation	Part No.	RLC	Part	Location
Adhesive Battery Cover Bottom	306Q1YE0200	C		
Adhesive Battery Cover Left	306Q1YE0300	C		
Adhesive Battery Cover Right	306Q1YE0400	C		
Adhesive Battery Cover Top	306Q1YE0100	C		
Adhesive Camera Key FPC	XXKS101620W	C		
Adhesive Ear Speaker	306M1X60300	C		














Designation	Part No.	RLC	Part	Location
Adhesive Front Camera	306Q1YE0B00	C		
Adhesive Front Flash LED PCB	306Q1YE0700	C		
Adhesive LCM Left Side	306Q1YE0C00	C		
Adhesive LCM Right Side	306Q1YE0D00	C		
Adhesive NFC	306Q1YE0A00	C		
Adhesive Power_Volume Key FPC	XXKS101619W	C		
Adhesive Side Key FPC Main	XXKS101623W	C		
Adhesive Side Key FPC_B	XXKS101621W	C		



Designation	Part No.	RLC	Part	Location
Adhesive Side Key FPC_C	XXKS101622W	C		
Adhesive Vibrator	XXKS101626W	C		
Audio Jack FPC Assy	21BY8600Y00	C		
Battery	1307-1549	C		
<u>Battery Cover Assy</u> Battery Cover Assy Black Battery Cover Assy White Battery Cover Assy Gold Battery Cover Assy Pink	78PB3500010 78PB3500020 78PB3500030 78PB3500040	B		
Bracket Main Camera	305A1YE0200	C		
<u>Cap Tray Dual</u> Cap Tray Dual Black Cap Tray Dual White Cap Tray Dual Gold Cap Tray Dual Pink Only for G3212, G3226!	306J1YE0400 306J1YE0300 306J1YE0600 306J1YE0E00	C		
<u>Cap Tray Single</u> Cap Tray Single Black Cap Tray Single White Cap Tray Single Gold Cap Tray Single Pink Only for G3221, G3223!	306J1YE0200 306J1YE0100 306J1YE0500 306J1YE0D00	C		













Designation	Part No.	RLC	Part	Location
Contact Clip Speaker Box	30551X60300	C		
Copper Foil Battery Cover	306F1YE0300	C		
CU Label	XXKS100968W	C		
CU Label Tray	306L1YE0800	C		
<u>Display Cover Assy</u> Display Cover Assy Black Display Cover Assy White Display Cover Assy Gold Display Cover Assy Pink	78PB3400010 78PB3400020 78PB3400030 78PB3400040	A		
Ear Speaker	22400000Q00	C		
Film Mylar Battery Left	306L1YE0700	C		
Film Mylar Battery Right	306L1YE0600	C		

Designation	Part No.	RLC	Part	Location
Front Camera	76510002A00	B		
Front Flash LED PCB	76520000P00	C		
<u>Key Camera</u> Key Camera Black Key Camera White Key Camera Gold Key Camera Pink	31251YE0300 31251YE0200 31251YE0600 31251YE0700	C		
<u>Key Power_Volume</u> Key Power_Volume Black Key Power_Volume White Key Power_Volume Gold Key Power_Volume Pink	31251YE0400 31251YE0100 31251YE0500 31251YE0800	C		
<u>Main Antenna Speaker Box</u> Main Antenna Speaker Box G3212 Main Antenna Speaker Box G3221/G3226 Main Antenna Speaker Box G3223	22500002U00 22500002X00 22500002V00	C		
Main Camera	C/76510002300	B		
Main Camera Lens Assy	78PB3300010	C		
NFC Antenna	2300BY86100	C		
RF Cable Black Only for G3221, G3223, G3226!	C/73200001600	C		

Designation	Part No.	RLC	Part	Location
RF Cable Grey Only for G3212!	C/73200001500	C		
RF Cable White Only for G3221, G3223, G3226!	C/73200001700	C		
Rubber 2nd MIC	302A1YE0800	C		
Rubber BTB Audio Jack	302A1YE0100	C		
Rubber BTB Front Camera	302A1YE0200	C		
Rubber BTB LCM	302A1YE0500	C		
Rubber BTB Main Camera	302A1YE0300	C		
Rubber BTB Sidekey FPC	302A1YE0400	C		
Rubber BTB Sub PBA	302A1X60100	C		

Designation	Part No.	RLC	Part	Location
Rubber Front Camera	302A1YE0900	C		
Rubber Front Flash LED	302A1YE0700	C		
Rubber Main Camera	302A1YE0B00	C		
Rubber PL Sensor	302A1YE0600	C		
Screw TORX M1.2 L2.5 Silver	C/27000005900	C		   

Designation	Part No.	RLC	Part	Location
<u>Side Panel Left</u> Side Panel Left Black Side Panel Left White Side Panel Left Gold Side Panel Left Pink	254F1YE0400 254F1YE0300 254F1YE0700 254F1YE0A00	C		
<u>Side Panel Right</u> Side Panel Right Black Side Panel Right White Side Panel Right Gold Side Panel Right Pink	254F1YE0200 254F1YE0100 254F1YE0600 254F1YE0900	C		
Sidekey FPC Assy	78PB3200010	C		
<u>Speaker Mesh</u> Speaker Mesh Black Speaker Mesh White Speaker Mesh Gold Speaker Mesh Pink	306M1YE0200 306M1YE0700 306M1YE0800 306M1YE0B00	C		
Speaker Sponge	306M1YE0900	C		
Sponge 1st Mic	303M1YE0100	C		
Sponge BTB Main Camera	303M1X60800	C		
Sponge Main PBA Single SIM Only for G3221, G3223!	303M1YE0800	C		

Designation	Part No.	RLC	Part	Location
Sponge Notification LED	303M1YE0400	C		
Sub Antenna	2300BY86200	C		
<u>Sub PBA Assy</u> Sub PBA Assy G3212 Sub PBA Assy G3221 Sub PBA Assy G3223 Sub PBA Assy G3226	78PB4100010 78PB3600010 78PB5100010 78PB3600020	C		
Vibrator	C/29300001200	C		
Water Intrusion Label	82KB600001W	C		
Water Intrusion Label Rectangle	82VY580001W	C		

2 History

Rev.	Date	Changes / Comments
1	2017-Apr-28	Initial release
2	2017-May-10	Added notes for some parts which model name is applicable for.