

Part List

- mechanical -



LT22i

CONTENTS

1 **Part List 3**


2 **Revision History 10**

















1 Part List

















The following parts are available for order in 'E-star'.









The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.

Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.













Designation	Part No.	Part	Location
Antenna NFC Flex	1252-5125		
Audio Jack	1242-3994		
<u>Battery</u> Battery 1265.0 mAh	1252-3213		
<u>Camera</u> Camera 8 MPixel CMOS	1249-7755		
<u>Cap Cosmetic cap assy</u> Cap Cosmetic cap assy Black Cap Cosmetic cap assy Red Cap Cosmetic cap assy Silver Cap Cosmetic cap assy Pink	1254-0058 1257-5720 1254-7028 1266-0029		
<u>Cap Metal Sim</u> Cap Metal Sim Black Cap Metal Sim Red Cap Metal Sim Silver Cap Metal Sim Pink	1251-4873 1257-6368 1252-5118 1265-9827		











Designation	Part No.	Part	Location
<u>Cap Top Assembly</u> Cap Top Assembly Black Cap Top Assembly Red Cap Top Assembly Silver Cap Top Assembly [Orange] Black Cap Top Assembly [Orange] Silver Cap Top Assembly [Orange] Red Cap Top Assembly TIM IT Silver Cap Top Assembly TIM IT Black Cap Top Assembly Pink	1254-3412 1257-5287 1254-3409 1263-1929 1263-1932 1263-1938 1263-1963 1263-1964 1266-0032		
Carrier Antenna Assy	1251-4854		
Carrier Internal Frame Assembly	1252-5126		
Carrier LCD Assembly	1251-7754		
Carrier LCD Flex Support Assembly	1254-1011		
Compass tape	1254-4708		
Connector Grommet	1252-5102		
Core Unit Label	1252-4880		

Designation	Part No.	Part	Location
Cover Plastic NFC Slit	1252-5123		
<u>Cover Rear Metal Assy</u> Cover Rear Metal Assy Black Cover Rear Metal Assy Red Cover Rear Metal Assy Silver Cover Rear Metal Assy Pink	1251-0967 1257-6389 1252-5114 1265-1874		
Cushion Conductive Grounding	1254-3993		
Cushion Grounding Pad 1	1254-0940		
Cushion Thermal Interface Pad 2	1254-0946		
<u>Display</u> Display 4.0 inch LTPS TFT	1250-8399		
<u>Ear Speaker</u> Ear Speaker 15.0 Rectangular	1231-4565		
Foil Adhesive Double Side Camera Sealing	1253-6653		

Designation	Part No.	Part	Location
Foil Adhesive Double Side Flash Lens	1253-2277		
Foil Adhesive Double Side Flash Silicone	1253-6675		
Foil Adhesive Double Side LCD Flex	1252-5155		
Foil Battery Adhesive	1252-0901		
Front Grommet Assembly	1256-9823		
Gasket	1254-4580		
Gasket Earspeaker	1252-0900		
Gasket HDMI Shield Can Gasket 3.4 x 3.4 Conductive HDMI Shield	1262-9832		

Designation	Part No.	Part	Location
<u>Gasket LMU Shield Can</u> Gasket 7x2.2 Conductive LMU Sheild Can	1262-7321		
<u>Gasket Loudspeaker</u> Gasket Loudspeaker Black Gasket Loudspeaker Silver	1253-9171 1253-9172		
Gasket Vibrator	1261-9201		
<u>Key Camera</u> Key Camera Black Key Camera Red Key Camera Silver Key Camera Pink	1251-0969 1257-6484 1252-5128 1265-9892		
<u>Key Volume / Power</u> Key Volume / Power Black Key Volume / Power Red Key Volume / Power Silver Key Volume / Power Pink	1251-0970 1257-6630 1252-5127 1265-9896		
Liquid Indicator	1001-0084		
PBA Interconnect Flex	1252-4589		
PBA Key flex	1251-4024		

Designation	Part No.	Part	Location
PBA Microphone flex	1251-4032		
Screw M1.4x3.5	1204-8506		
<u>Cosmetic side screw</u> Cosmetic side screw grey Cosmetic side screw black	1254-3969 1261-1813		
Screw Other Len:0.0 Diam:0.0 Screw Black	1257-1394		
Screw Other Len:2.0 Diam:1.2 M1.2x2.0	1253-7696		
Screw Philips Len:3.0 Diam:1.2	1264-8553		

Designation	Part No.	Part	Location
Touch Flex Shielding	1264-3866		
Transparent Belt Assembly	1251-4864		
Vibrator	1001-1163		
Water Indicator 3x3	1223-5172		
Window Flash Lens	1251-4870		

2 Revision History

Rev.	Date	Changes / Comments
1	2012-May-7	Initial release
2	2012-July-11	1212-3670 removed, 1264-8553, 1265-1874, 1265-9827, 1265-9892, 1265-9896, 1266-0029, 1266-0032 added
3	2012-Aug-22	No update, revision due to doc. release failure.