

## Repair Movies

- mechanical -



**Xperia™ V**  
**LT25i**



**Xperia™ VC**  
**LT25c**

## CONTENTS

<b>1</b>	<b>Movies-LT25i.....</b>	<b>3</b>
1.1	Disassembly .....	3
1.2	Reassembly .....	3
<b>2</b>	<b>Movies-LT25c.....</b>	<b>4</b>
2.1	Disassembly .....	4
2.2	Reassembly .....	4
<b>3</b>	<b>Revision History .....</b>	<b>5</b>

***To view the embedded repair movies in this document, Acrobat Reader version 8 (or later) and Flash Player version 8 (or later) must be installed on your computer.***

***For best picture quality, select “Actual size” or “100%” as zoom level in Acrobat Reader.  
To magnify while keeping an acceptable picture quality, increase the zoom level to 200%.***

***If the movies appear to be jerky or blurred when viewing on-line, this is probably caused by the connection speed being too slow.  
In that case, right-click with the mouse on the document name and select Save Target As to download the repair movie document for off-line viewing.***

***For general information about repair movies, refer to  
1220-1333: Generic Repair Manual - mechanical***



## 1 Movies-LT25i


### 1.1 Disassembly

- Cover Battery Assy
- Battery
- Cover Rear Assy
- Cap Micro USB
- Main Gasket
- Sheet Side Key FPC
- Relay Flex PBA Assy
- Main Camera
- Jack Flex PBA Assy
- Touch/Display Front Cover Assy
- Cable RF (a) & Main PBA (b)



### 1.2 Reassembly

- Cable RF (a) & Main PBA (b)
- Touch/Display Front Cover Assy
- Jack Flex PBA Assy
- Main Camera
- Relay Flex PBA Assy
- Sheet Side Key FPC
- Main Gasket
- Cap Micro USB
- Cover Rear Assy
- Battery
- Cover Battery Assy



## 2 Movies-LT25c

### 2.1 Disassembly

- Cover Battery Assy
- Battery
- Cover Bottom
- Cover Rear Assy
- Cap Micro USB
- Main Gasket
- Sheet Side Key FPC
- Relay Flex PBA Assy
- Main Camera
- Jack Flex PBA Assy
- Touch/Display Front Cover Assy
- Cable RF (a) & Main PBA (b)



### 2.2 Reassembly

- Cable RF (a) & Main PBA (b)
- Touch/Display Front Cover Assy
- Jack Flex PBA Assy
- Main Camera
- Relay Flex PBA Assy
- Sheet Side Key FPC
- Main Gasket
- Cap Micro USB
- Cover Rear Assy
- Cover Bottom
- Battery
- Cover Battery Assy



## 3 Revision History

Rev.	Date	Changes / Comments
1	2012-Nov-16	Initial release