

Repair Movies - mechanical -



Xperia S

LT26i, LT26ii, SO-02D

CONTENTS

1 Movies 3
 1.1 Disassembly 3
 1.2 Reassembly 3
2 Revision History 4

To view the embedded repair movies in this document, Acrobat Reader version 8 (or later) and Flash Player version 8 (or later) must be installed on your computer.

For best picture quality, select “Actual size” or “100%” as zoom level in Acrobat Reader. To magnify while keeping an acceptable picture quality, increase the zoom level to 200%.

If the movies appear to be jerky or blurred when viewing on-line, this is probably caused by the connection speed being too slow. In that case, right-click with the mouse on the document name and select Save Target As to download the repair movie document for off-line viewing.

*For general information about repair movies, refer to
1220-1333: Generic Repair Manual - mechanical*

1 Movies


1.1 Disassembly

1. Cover Rear Assy
2. Cover Bottom
3. Battery
4. Rear Frame Assy
5. Main Camera
6. Main PBA
7. Cover Transparent Assy
8. Cover Front Assy



1.2 Reassembly

1. Cover Front Assy
2. Cover Transparent Assy
3. Main PBA
4. Main Camera
5. Rear Frame Assy
6. Battery
7. Cover Bottom
8. Cover Rear Assy



2 Revision History

Rev.	Date	Changes / Comments
1	2012-Mar-2	Initial release
2	2012-Mar-7	Template update
3	2012-Agu-23	Commercial name update