

Repair Movies

- mechanical -



ST27i, ST27a

CONTENTS

1 Movies 3
 1.1 Disassembly 3
 1.2 Reassembly 3
2 Revision History 4

To view the embedded repair movies in this document, Acrobat Reader version 8 (or later) and Flash Player version 8 (or later) must be installed on your computer.

For best picture quality, select “Actual size” or “100%” as zoom level in Acrobat Reader. To magnify while keeping an acceptable picture quality, increase the zoom level to 200%.

If the movies appear to be jerky or blurred when viewing on-line, this is probably caused by the connection speed being too slow. In that case, right-click with the mouse on the document name and select Save Target As to download the repair movie document for off-line viewing.

For general information about repair movies, refer to 1220-1333: Generic Repair Manual - mechanical

1 Movies

1.1 Disassembly

1. Battery Cover Assy
2. SIM Drawer
3. Cover Front Housing Display Assy
4. Main Camera
5. Audio Jack FPC
6. Back Housing Assy (a) & Main PBA (b)



1.2 Reassembly

1. Back Housing Assy (a) & Main PBA (b)
2. Audio Jack FPC
3. Main Camera
4. Cover Front Housing Display Assy
5. SIM Drawer
6. Battery Cover Assy



2 Revision History

Rev.	Date	Changes / Comments
1	2012-Jun-25	Initial release
2	2012-Jul-3	Update phone direction on Pressure Tool.