



Sony Ericsson

---

# Part List

## - mechanical -



*XPERIA X10 Mini Pro*

*U20i, U20a*



## CONTENTS

1	Part List .....	3
2	Revision History .....	9













# 1 Part List

The following parts are available for order in 'E-star'.

The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.

Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.
















Designation	Part No.	Part	Location
Base Cover Middle Deco belt	1234-7325		
<u>Battery Cover</u> Battery Cover Assembly Black Battery Cover Assembly Red Battery Cover Assembly White Battery Cover Assembly Pink Battery Cover Assembly Lime	1229-9358 1233-5351 1236-3559 1236-3545 1236-3555		
<u>Bottom Carrier Frame Assy</u> Bottom Carrier Frame Assy (1.2.5 Band) Bottom Carrier Frame Assy (1.8 Band)	1229-9687 1236-0829		
Camera 5 MPixel	1229-3662		
Camera Gasket	1230-8897		
<u>Camera Key</u> Camera Key Black Camera Key Red Camera Key White Camera Key Pink Camera Key Lime	1229-8398 1234-2037 1237-8028 1238-1029 1238-1032		
Camera Window	1230-6148		

















Designation	Part No.	Part	Location
Carrier Metal Qwerty Support Assy	1230-7005		
Carrier Plastic Qwerty Support Assembly	1229-2161		
CCR-80 micro SD memory adapter, black	1226-9295		
Center Qwerty Support	1235-4392		
<u>Cobrand label</u> Cobrand label XPERIA/Black Cobrand label XPERIA/Red Cobrand label XPERIA/White Co-brand Label Pink Co-brand Label Lime	1233-0163 1236-4616 1237-9967 1237-9977 1237-9976		
Core unit label	1232-1232		
Cushion 0.0 mmConductive Camera Support	1230-7007		
Cushion Grounding Hinge	1222-8588		

Designation	Part No.	Part	Location
<u>Display</u> Display 2.55 TFT QVGA	1227-8211		
Ear Speaker	1222-5301		
Flash Lens Foil Adhesive	1232-8744		
Flash Lens Window	1230-1533		
Foil Adhesive Double Side Conductive 0.0	1232-5130		
Front Cover Assembly	1236-8726		
Gasket Conductive 3,8x2,3	1233-2177		
Gasket Ear Speaker	1229-4387		



Designation	Part No.	Part	Location
Hinge assembly	1230-1020		
Key lock/onoff	1229-8394		
<u>Keyboard</u> Keyboard Azerty Latin Keyboard Bopomofo QWERTY Keyboard Chinese QWERTY Keyboard Cyrillic QWERTY Keyboard Danish/Norwegian QWERTY Keyboard Greek QWERTY Keyboard Latin QWERTY Keyboard Portuguese QWERTY Keyboard Qwertz Latin Keyboard Swedish/Finish QWERTY	1236-2759 1236-2776 1236-2787 1236-2762 1236-2785 1236-2761 1229-8389 1236-2786 1236-2757 1236-2784	          	          
Loudspeaker Mesh	1230-1227		
MH810 Remote control headset Black MH810 Headset Pearl White MH810 Headset Red MH810 Headset Pink MH810 Headset Lime	1231-6484 1233-8926 1233-8927 1233-8928 1233-8929		
<u>Micro SD</u> Micro SD 2Gb Micro SD 4Gb Micro SD 8Gb Micro SD 16Gb	1218-7894 1210-7834 1210-7835 1222-7995	    	    
PBA AVP assy	1230-1278		

Designation	Part No.	Part	Location
PBA Dome, Complete	1229-9805		
PBA H2H Flex	1228-2364		
<u>PHF Stereo MH610</u> PHF Stereo MH610, Black	1236-1423		
Plastic Cover Proximity	1229-9998		
Screw Philips Len:1.6 Diam:1.4 Screw M1,	1232-8155		
Screw Philips Len:3.0 Diam:1.4	1232-2921		
Screw Philips Len:5.5 Diam:1.4	1232-2804		
Screw Torx T5 Len:5.0 Diam:1.6 No color	1232-8169		

Designation	Part No.	Part	Location
Shield Can Camera	1230-1282		
Shield Can Lid BB	1227-4450		
Shield Can Lid Radio	1227-4451		
Shield Can Lid WLAN	1227-4453		
<u>Volume Key</u> Volume Key Black Volume Key Red Volume Key White Volume Key Pink Volume Key Lime	1229-8400 1234-2043 1237-8026 1238-1036 1238-1039		
Water Indicator 3x3	1223-5172		
			
Tape Insulation Touch	1243-6754		





## Revision History

Rev.	Date	Changes / Comments
1	2010-June-28	Initial release
2	2010-June-28	Updated with MH810 Headset Pearl White (1233-8926) and MH810 Headset Red (1233-8927)
3	2010-June-30	Removed “(Not available for order before week 29) “ from Front Cover Assembly
4	2010-Sept-24	Added Pink and Lime parts
5	2010-Sep-28	Added Gasket Ear Speaker spare part
6	2010-Dec-27	Tape insulation Touch added.
7	2011-Mars-08	No update