

Test Instruction, Electrical

Applicable for F305

Contents

1	General.....	2
2	Test Procedure	2
3	Test flow	2
3.1	Software Update	2
4	Go/No-Go Test.....	3
4.1	Go/No-Go Test Preparations	3
4.2	SERP GNG	4
4.3	Stand alone GNG.....	4
5	Revision History	5

1 General

This document describes the test procedures for the electrical repair package.

2 Test Procedure

To verify all components within the Electrical repair package, all tests must be performed.

3 Test flow

If the phone passes these tests without any failures, it is OK to return it to the customer.
If there are any failures, the phone must be repaired according to the troubleshooting guide or sent to a higher repair level.

3.1 Software Update

Update to latest signalling software and run the service activities software from EMMA

3.1.1 Verify Software Version

NOTE! Remove the SIM-card before testing.

To verify if the phone needs new software, you have to check the Software Version in the phone. Current Software Versions are checked through the following steps:

1. Start up the phone.
2. Enter the Service Tests Menu by pressing the sequence **►*◄◄*◄*** with the navigate buttons and the ***** on the keypad.
3. Select Service info.
4. Select SW Information.
5. Check the file revisions on the display.
6. Press “back” key to return to the Service info menu.

3.1.2 Update Software Version

Update the software in the phone by doing the following steps:

1. Make sure that the phone's battery is fully charged or use a battery eliminator. Connect correct flash cable and interface according to the Installation instruction.
2. Logon to the EMMA server, and follow the instructions

4 Go/No-Go Test

This test verifies that the radio parameters of a mobile fulfil the GSM / WCDMA specifications. A mobile is considered good if all measurements pass. All results will be presented on the screen and can be printed out if a printer is available.

There are two options available for performing the GNG test, SERP GNG or a Stand alone GNG. The SERP GNG can be downloaded from CSPN as described in Installation Instructions, Electrical (1220-2578). To perform a Stand alone GNG a test script must be written in accordance with the GO/NO GO Test Script Specification, Electrical (1220-4598) located on CSPN.

4.1 Go/No-Go Test Preparations

4.1.1 RF Probe (Conducted Test Method)

1. Remove the battery cover according to Working Instructions, Mechanical.
2. Insert a test USIM that is compatible with your Test Instrument and install a fully charged standard battery to the mobile.
3. Install the RF Probe to the RF Cable and attach to the mobile according to the picture.



4.1.2 RF Coupler (Radiated Test Method) TBD RTL+6w

4.2 SERP GNG

NOTE! For complete and detailed user instructions, see the *SERP Users Manual* located in the *SERPINFO.htm* that gets placed on the Desktop after SERP is installed.

1. On a PC with SERP installed, start the SERP program by double clicking on the "**RepairManager.exe**" icon on the desktop.
2. Click on "**Settings**" in the SERP Window and verify that the test instrument and the GPIB address correspond.
3. Click on the "**Station Setup**" tab and verify that the setting in the "**RF Connection-GoNogo**" Drop down window is correct. Click on "**Apply**" and then the "**OK**" button.
4. Enter (or scan) the IMEI number of the mobile to be tested into the "**Enter IMEI**" box in the SERP Window and click on the "**Load**" button. The appropriate phone model will be displayed.
5. In the SERP window, check the "**Final GoNogo Test**" box only. Click on the "**Start Test**" button and follow the instructions. (Power on the phone when the "**Call Connection**" dialog box appears.)

4.3 Stand alone GNG

A Stand alone GNG test script must be written in accordance with the GO/NO GO Test Script Specification, Electrical (1220-4598) located on CSPN.

5 Service Tests

5.1 Main Display Test

To verify the display:

1. Select “Main Display” from the “Service Tests” menu.
2. The display toggles between four different test patterns.
Make sure that there are no dots missing and that the colours and contrast is OK.
3. Press the “centre navi” key to go back to the service tests menu.

5.2 LED/Illumination Test

To verify that the backlight and the LEDS are OK:

1. Select “LED/illumination” from the “Service Tests” menu.
2. Check that the backlight in the display and the keyboard is toggle between on and off.
3. Press “centre navi” key to go back to the service tests menu.

5.3 Keyboard Test

To verify that all the keys are working:

1. Select “Keyboard” from the “Service Tests”.
2. Press all keys on the keypads and the ”Side Up” and “Side Down” keys on the right side and close Flip . If they are OK a text feedback is displayed showing the information which key was pressed. All keys should be tested.
3. If you stop pressing keys the phone will return to the service test menu.

5.4 Speaker Test

Warning! Do NOT hold the phone to your ear while performing this test.

To verify the Speaker function:

1. Select “Speaker” from the “Service Tests” menu.
2. Adjust the volume and make sure that the Speaker is working properly.
3. Press the “centre navi” key to go back to the service tests menu.

5.5 Earphone Test

Earphone service test currently has SW rooting Error, the Audio Melody signal has been directed to the loudspeaker not Earphone, therefore for temporary testing refer to section 5.4 of test instruction.

This issue will be solved in MR1 release SW.

5.6 Microphone Test

This test is intended to test the microphone. Therefore, the earphone should be tested before this test is entered.

1. Select "Microphone" from the "Service Tests" menu.
2. The phone will start to record and after that the sound is played in the loud speaker. Make sure that the record sounds have a loud and clear sound.
3. The phone will automatically return to the service tests menu when "Microphone Playing" is completed.

5.7 Vibrator alert Test

To verify the vibrator function:

1. Select "Vibrator" from the "Service Tests" menu.
2. Press any key and the vibrator will vibrate 3 times.
3. Press the "central navi" OK key to go back to the service tests menu.

5.8 Camera Test

To verify the camera functionality:

1. Select Camera from the "Service Tests" menu.
2. The camera function will now start and are visible in the display. Make sure that the contrast is OK.
3. Press the "right soft-Back" key to go back to the service tests menu

5.9 Memory card Test

This test is to verify if the communication to the memory card is working.

1. Insert a memory card into the memory card holder located on the lower left side of the phone.
2. Select "Memory Card" from the "Service tests" menu.
3. Make sure that the phone will detect the memory card.
4. Remove the memory card from the holder.

Press the "central navi" OK key to go back to the service tests menu.

5.10 FM Radio Test

To verify the function of the FM radio:

1. Install a Portable Hands-Free (PHF) to the system connector.
2. Select "FM radio" from the "Service Tests" menu and press the "Select" key.
3. Using the keypad set the frequency to a known good FM station.
4. While listening to the FM station with the PHF ensure that the sound quality compares to a known good handset.
5. Remove the PHF and press the "central navi" OK key to end the test.

5.11 Total call time Test

This test will show you the Total Call Time of the phone.

1. Select "Total Call Time" from the "Service Tests" menu and you will get information regarding the "Total Call Time" of this phone.
2. Press the "central navi" OK key to go back to the service tests menu.

6 Manual Tests

6.1 On The Air Call To Mobile

To verify the function of the speaker, microphone, polyphonic ring signal and volumes button.

1. Insert an operator SIM card and start the phone.
2. Set up a call from another phone to the mobile phone.
3. Answer the phone call.
4. Check that the polyphonic ring signal is working and that the backlight switches on OK.
5. Also check that the quality of the sound both in the mobile phone and the other phone are OK.
6. Press the volume key up and down and check that the volume in the phone is altered.
7. End the call.
8. Check that the ending procedure is OK and that the speech time is displayed.

6.2 Bluetooth Test

To verify that the Bluetooth communication is working:

1. Insert a SIM card, connect a battery and start the unit.
2. Activate the Bluetooth function by entering Connectivity/Bluetooth and turn it on.
3. Set up a link between the phone and another Bluetooth compatible device. If a connection can be established the Bluetooth module is considered working.

6.3 System Connector Test

Hands free equipment and a charger are used in this test, to check the functionality of the System Connector.

1. Insert a SIM card, connect a battery and start the unit.
2. Connect the Hands free equipment to the system connector and set up a call and listen if you can speak/hear in the hands free set.

6.4 Earphone Test

To verify that the Earphone is working:

1. Insert a SIM card, connect a battery and start the unit.
2. Set up a call from another phone to the mobile phone, and listen if you can hear in the earphone.
3. Also check that the quality of the sound both in the mobile phone and the other phone are OK.
4. Press the volume key up and down and check that the volume in the phone is altered.
5. End the call.

7 Revision History

Rev.	Date	Changes / Comments
1	2008-10-10	First release
2	2008-11-04	Service Test Added