



Test Instruction - Electrical

Applicable for W900i

1	Abstract	2
2	Test Procedure	2
3	Test flow	2
3.1	Software Update	2
3.1.1	Verify Software Version	2
3.1.2	Update Software Version.....	2
3.2	Go/No-Go Test	3
3.2.1	GSM and WCDMA part.....	3
3.3	Service Tests	4
3.3.1	Main Display Test	4
3.3.2	LED/Illumination Test	4
3.3.3	Keyboard Test	4
3.3.4	Speaker Test	4
3.3.5	Earphone Test.....	5
3.3.6	Microphone Test	5
3.3.7	Vibrator Test	5
3.3.8	Camera Test.....	5
3.3.9	Video Call Camera Test.....	5
3.3.10	Flash LED Test.....	6
3.3.11	Memory stick test.....	6
3.3.12	Real Time Clock Test.....	6
3.3.13	Total Call Time test.....	6
3.3.14	On The Air Call To Mobile	7
3.3.15	Infrared Test	7
3.3.16	Bluetooth Test	7
3.3.17	System Connector Test	7
4	Revision History	8

1 Abstract

This document describes the test procedure for the Electrical repair package.

2 Test Procedure

To verify all components within the Electrical repair package, all tests must be performed.

3 Test flow

If the phone passes these tests without any failures, it is OK to return it to the customer.
If there are any failures, the phone must be repaired according to the troubleshooting guide or sent to a higher repair level.

3.1 Software Update

Update to latest signalling software and run the service activities software from EMMA III.

3.1.1 Verify Software Version

To verify if the phone needs new software, you have to check the Software Version in the phone. Current Software Versions are checked through the following steps:

1. Start up the phone.
2. Press the following navigate-button and keyboard sequence: ⇨ * ⇐ ⇐ * ⇐ *
3. Select Service info.
4. Select SW Information.
5. Check the file revisions on the display.
6. Press OK to return to the Service info menu.

3.1.2 Update Software Version

Update the software in the phone by doing the following steps:

1. Make sure that the phone's battery is fully charged or use a battery eliminator. Connect correct flash cable and interface according to the Installation instruction.
2. Logon to the EMMA III server, and follow the instructions.

3.2 Go/No-Go Test

NOTE! For testing the GSM / WCDMA part use instrument Yokogawa VC 230.

3.2.1 GSM and WCDMA part

If all measurements are approved, this will be confirmed. If any faults are discovered, this will be presented either on the screen. Repair the unit according to the Troubleshooting guide or send the phone to higher repair level.

It's possible to do this test either with antenna coupler from Rohde&Schwarz or RF adapter. When using RF adapter a battery eliminator together with a power box can be used.

It's very important that a fully charged battery is used otherwise there is a risk for wrong test results.

Antenna Coupler

- Insert a test-SIM and a fully charged standard battery. Position the phone in the coupler according to the picture (Fig 1).

RF adapter

- Insert a test-SIM and the battery eliminator or a fully charged standard battery. Assemble the RF adapter according to Fig 2 and 2.1. Connect the RF cable between the Test set and the antenna adapter.

Picture R&S will be added in a later release

Fig. 1

Picture in RF holder will be added in a later release

Fig. 2

Picture in RF holder will be added in a later release

Fig. 2.1

1. Start the instrument, and run the correct script for W900i, depending how the measurement will be performed, with coupler or with RF-holder (Hard line).
2. Follow the instructions on the Test instrument during the test.

3.3 Service Tests

Power up the phone.

NOTE! It is not necessary to have a SIM card inserted.

The Service Tests menu is entered by using the following navigate-button and key sequence: → * ← → * ← → * and select "Service Tests".

3.3.1 Main Display Test

To verify the display:

1. Select "Main display" from the "Service Tests" menu.
2. The display toggles between four different test patterns.
Make sure that there are no dots missing and that the colours and contrast is OK.
3. Press the "↵" key to go back to the service tests menu.

3.3.2 LED/Illumination Test

To verify that the backlight and the red led are OK:

1. Select "LED/illumination" from the "Service Tests" menu.
2. Check that the backlight in the display and the keyboard is toggle between on and off.
3. Also check that the red led on the front is toggle between red and off.
4. Press the "Ok" key to go back to the service tests menu.

3.3.3 Keyboard Test

To verify that all the keys are working:

1. Select "Keyboard" from the "Service Tests".
2. Press all keys on the keypad, the camera and the flash led key on the right side and the volume keys on the left side. If they are ok a text feedback is displayed showing the information which key was pressed. All keys should be tested.

If you stop pressing keys the phone will return to the service test menu.

3.3.4 Speaker Test

Warning! Do NOT hold the phone to your ear while performing this test.

To verify the Speaker function:

1. Select "Speaker" from the "Service Tests" menu.
2. Adjust the volume and make sure that the Speaker is working properly.

Press the "Ok" key to go back to the service tests menu.



3.3.5 Earphone Test

To verify the Earphone function:

1. Select "Earphone" from the "Service Tests" menu.
2. Adjust the volume and make sure that the Earphone is working properly.
3. Press the "Ok" key to go back to the service tests menu.

3.3.6 Microphone Test

This test is intended to test the microphone. Therefore, the earphone should be tested before this test is entered.

1. Select "Microphone" from the "Service Tests" menu.
2. The phone will start to record and after that the sound is played in the speaker. Make sure that the record sounds have a load and clear sound.
3. Press the "Ok" key to go back to the service tests menu.

3.3.7 Vibrator Test

To verify the vibrator function:

1. Select "Vibrator" from the "Service Tests" menu.
2. Press any key and the vibrator will vibrate 3 times.
3. Press the "Ok" key to go back to the service tests menu.

3.3.8 Camera Test

To verify the camera functionality:

1. Select Camera from the "Service Tests" menu.
2. The camera function will now starts and are visible in the display. Make sure that the contrast and light is OK.
3. Press the "↵" key to go back to the service tests menu.

3.3.9 Video Call Camera Test

To verify the Video call camera functionality:

4. Select Video call camera from the "Service Tests" menu.
5. The video call camera function will now starts and are visible in the display. Make sure that the contrast and light is OK.
6. Press the "↵" key to go back to the service tests menu.



3.3.10 Flash LED Test

To verify that the backlight and the red led are OK:

5. Select "LED/illumination" from the "Service Tests" menu.
6. Check that the backlight in the display and the keyboard is toggle between on and off.
7. Also check that the red led on the front is toggle between red and off.
8. Press the "Ok" key to go back to the service tests menu.

3.3.11 Memory stick test

This test is to verify if the communication to the memory stick is working.

1. Insert a memory stick in to the memory stick holder.
2. Select "Memory Stick" from the "Service tests" menu.
3. Make sure that the phone will detect the memory stick.
4. Remove the memory stick from the holder.

3.3.12 Real Time Clock Test

This test will check if the built in real time clock works.

1. Select "Real time clock" from the "Service Tests" menu.
After approximately 5 seconds you will get information whether the clock is ok or not.
2. Press the "Ok" key to go back to the service tests menu.

3.3.13 Total Call Time test

This test will show you the Total Call Time of the phone.

1. Select "Total Call Time" from the "Service Tests" menu
and you will get information regarding the "Total Call Time" of this phone.
2. Press "Ok" key to return to the service tests menu.

3.3.14 On The Air Call To Mobile

To verify the function of the speaker, microphone, polyphonic ring signal and volumes button.

1. Insert an operator SIM card and start the phone.
2. Set up a call from another phone to the mobile phone.
3. Answer the phone call.
4. Check that the polyphonic ring signal is working and that the backlight switches on OK.
5. Also check that the quality of the sound both in the mobile phone and the other phone are OK.
6. Press the volume key up and down and check that the volume in the phone is altered.
7. End the call.
8. Check that the ending procedure is OK and that the speech time is displayed.

3.3.15 Infrared Test

To verify that the Infrared communication is working:

1. Insert a SIM card, connect a battery and start the unit.
2. Activate the function by entering Connectivity/Infrared port and select "10 minutes".
3. Set up an infrared link between an IR device and the phone. The IR-module is placed on the right side of the phone. If a link can be established, the module is considered working.

3.3.16 Bluetooth Test

To verify that the Bluetooth communication is working:

1. Insert a SIM card, connect a battery and start the unit.
2. Activate the Bluetooth function by entering Connectivity/Bluetooth and turn it on.
3. Set up a link between the phone and another Bluetooth compatible device. If a connection can be established the Bluetooth module is considered working.

3.3.17 System Connector Test

Hands free equipment and a charger are used in this test, to check the functionality of the System Connector.

1. Insert a SIM card, connect a battery and start the unit.
2. Connect the Hands free equipment to the system connector and set up a call and listen if you can speak/hear in the hands free set.
3. Connect the charger to the system connector and see if the phone starts to charge and if the charging is indicated in the display.

4 Revision History

Rev.	Date	Changes / Comments
A	2005-11-23	First release